

655B and 755B Crawler Loader Repair

For complete service information also see:

655B and 755B Crawler Loader

Operation and Test TM1333
6068 Engine CTM8
6414 Engine CTM4
Starting Motor and Actuator CTM77
Undercarriage Appraisal Manual SP326

**John Deere Dubuque Works
TM1478 (11MAY94)**

LITHO IN U.S.A.
ENGLISH

**655B and 755B Crawler Loader
Repair**

TM1478 (11MAY94)



Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

N This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

JOHN DEERE DEALERS

IMPORTANT: Please remove this page and route through your service department.

This is a complete revision for TM-1478, 655B and 755B Crawler Loader.

Listed below is a brief explanation of "WHAT" was changed and "WHY" it was changed.

1. Removal and installation, disassembly and assembly of control pump and transmission charge pump, Group 0360.
2. Current information on fuel injection timing.
3. Current information on the air conditioning systems.
4. Current information on loader control valve.

Contents

SECTION 00—GENERAL INFORMATION

- Group 0001—Safety Information
- Group 0002—General Specifications
- Group 0003—Torque Values
- Group 0004—Fuels and Lubricants

SECTION 01—TRACKS

- Group 0130—Track System

SECTION 02—AXLES AND SUSPENSION SYSTEMS

- Group 0201—Drive Axle Housing and Support
- Group 0250—Axle Shaft, Bearings and Reduction Gears

SECTION 03—TRANSMISSION

- Group 0300—Removal and Installation
- Group 0315—Controls Linkage
- Group 0325—Input Drive Shafts And U-Joints
- Group 0360—Hydraulic System (Hydrostatic Transmission)

SECTION 04—ENGINE

- Group 0400—Removal and Installation
- Group 0416—Turbocharger
- Group 0417—Water Pump
- Group 0418—Thermostats
- Group 0421—Fuel Transfer Pump
- Group 0429—Fan Belt Tightener

SECTION 05—ENGINE AUXILIARY SYSTEM

- Group 0505—Cold Weather Starting Aids
- Group 0510—Cooling Systems
- Group 0515—Speed Controls
- Group 0520—Intake System
- Group 0530—External Exhaust System
- Group 0560—External Fuel Supply System

SECTION 07—CLUTCH (COLD WEATHER DISCONNECT)

- Group 0715—Controls Linkage
- Group 0752—Elements

SECTION 08—SPLITTER DRIVE

- Group 0851—Gears, Shafts and Bearings

SECTION 11—PARK BRAKE

- Group 1100—Removal and Installation
- Group 1111—Active Elements
- Group 1115—Controls Linkage
- Group 1160—Hydraulic System

SECTION 15—EQUIPMENT ATTACHING

- Group 1511—Drawbar
- Group 1512—Towbar

SECTION 16—ELECTRICAL SYSTEM

- Group 1671—Batteries, Support and Cables
- Group 1672—Alternator, Regulator and Charging System Wiring
- Group 1673—Lighting System
- Group 1674—Wiring Harness and Switches
- Group 1675—System Controls
- Group 1676—Instruments and Indicators
- Group 1677—Motors and Actuators

SECTION 17—FRAME, CHASSIS OR SUPPORTING STRUCTURE

- Group 1740—Frame Installation
- Group 1746—Frame Bottom Guards
- Group 1749—Chassis Weights

SECTION 18—OPERATOR'S STATION

- Group 1800—Removal and Installation
- Group 1810—Operator Enclosure
- Group 1821—Seat and Seat Belt
- Group 1830—Heating and Air Conditioning

SECTION 19—SHEET METAL AND STYLING

- Group 1910—Hood or Engine Enclosure
- Group 1921—Grille and Grille Housing

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1478-19-11MAY94

COPYRIGHT© 1994
DEERE & COMPANY
Moline, Illinois

All rights reserved
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright 1989, 1988, 1986, 1985 Deere & Company

SECTION 20—SAFETY, CONVENIENCE AND MISCELLANEOUS

- Group 2003—Fire Extinguisher
- Group 2004—Horn and Warning Devices
- Group 2006—Cigar Lighter

SECTION 31—LOADER

- Group 3102—Bucket
- Group 3115—Controls Linkage
- Group 3140—Frames
- Group 3160—Hydraulic System

SECTION 99—DEALER FABRICATED TOOLS

- Group 9900—Dealer Fabricated Tools

Index

00
01
02
03
04
05
07
08
11
15
16
17
18
19
20

31

99

INDX

31

99

INDX

Section 00 GENERAL INFORMATION

Contents

Page

Group 0001—Safety Information

Safety Signs 0001-1

Group 0002—General Specifications

655B Crawler Loader Specifications 0002-1

755B Crawler Loader Specifications 0002-3

Capacities 0002-5

Group 0003—Torque Values

Torque Valves 0003-1

Service Recommendations 0003-5

O-Ring Boss Fittings 0003-6

Flat Face O-Ring Seal Fittings 0003-7

Straight or Tapered Fittings 0003-8

Four-Bolt Flange Fittings 0003-9

Track Shoe Bolt Torque 0003-11

Master Link Track Shoe Bolt Torque 0003-12

Group 0004—Fuels and Lubricants

Use Periodic Maintenance Chart 0004-1

Fuel Specifications 0004-1

Fuel Storage 0004-1

Fuel Tank 0004-2

Engine Oil 0004-3

Hydraulic Oil 0004-4

Splitter Gearbox Oil 0004-4

Transmission Oil 0004-5

Final Drive Oil 0004-6

Roller and Idler Oil 0004-6

Grease 0004-7

Winch Oil 0004-8

Engine Coolant 0004-9

Alternative and Synthetic Lubricants 0004-9

Lubricant Storage 0004-9

HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90

0001
-JUN-23AUG88
TS227

PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



DX,SPARKS -19-03MAR93


-JUN-23AUG88
TS204

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

-JUN-23AUG88
TS291

PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



TS203 -UN-23AUG88

DX,POISON -19-21APR93


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




DX,FLUID -19-03MAR93

0001
3
-JUN-23AUG88
X9811

PARK MACHINE SAFELY

Before working on the machine:

- Lower all equipment to the ground.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.



DX,PARK -19-04JUN90


-JUN-24MAY89
TS230

0001
4

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



DX,LOWER -19-04JUN90

TS229 -JUN-23AUG88


WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




DX,WEAR -19-10SEP90

TS206 -JUN-23AUG88

SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.




DX,LOOSE -19-04JUN90

TS228 -JUN-23AUG88

WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.




DX,AIR -19-04JUN90

TS220 -JUN-23AUG88

0001
5

ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.



DX,LIGHT -19-04JUN90

TS223 -JUN-23AUG88

REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.




DX,SIGNS1 -19-04JUN90

TS201 -JUN-23AUG88

USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



DX,LIFT -19-04JUN90


TS226 -JUN-23AUG88

0001
6

KEEP ROPS INSTALLED PROPERLY

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.



DX,ROPS3 -19-03MAR93

TS212 -JUN-23AUG88


AVOID HARMFUL ASBESTOS DUST

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos.

Keep bystanders away from the area.




DX,DUST -19-15MAR91

TS220 -JUN-23AUG88

WORK IN CLEAN AREA

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.



DX,CLEAN -19-04JUN90

T6642EJ -JUN-18OCT88

0001
7

USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



DX,REPAIR -19-04JUN90

TS779 -JUN-08NOV89

0001
8

DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 -JUN-26NOV90

DX,DRAIN -19-03MAR93

LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



TS231 -19-07OCT88

DX,LIVE -19-25SEP92

REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



DX,PAINT -19-03MAR93

0001
9
-JUN-23AUG88
TS220

AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



DX,TORCH -19-03MAR93

-JUN-15MAY90
TS953

PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.



-JUN-23AUG88


TS218

DX,SERV

-19-03MAR93

0001
10

655B CRAWLER LOADER



T7227AA (CV)

T7227AA -JUN-12MAR90

- A—10 ft 1.5 in. (3.09 m)
- B—18 ft 6.5 in. (5.65 m)
- C—5.5 in. (140 mm)
- D—9 ft 2.5 in. (2.81 m)
- E—11 ft 10 in. (3.60 m)
- F—45°
- G—4 ft 0.0 in. (1.22 m)

specifications are in accordance with ICED and SAE standards. Except where otherwise noted, these specifications are based on a unit equipped with 2 cu. yd. (1.53 m³) bucket with teeth, roll-over protective canopy, four counterweights, full fuel tank, 175 lb (79 kg) operator, and standard equipment.

NOTE: Specifications and design subject to change without notice. Wherever applicable

TX,115,DH971 -19-16MAR92

0002
2

655B GENERAL SPECIFICATIONS

Specifications and design are subject to change without notice. Whenever applicable, specifications are in accordance with SAE standards. Except where otherwise noted, these specifications are based on a unit with a 2 cu yd (1.5 m³) bucket with teeth, roll-over protective canopy, four counterweights, full fuel tank, 175 lb (80 kg) operator and standard equipment.

| | | |
|--------------------------------|----------------|------------------|
| Rated Power @ 2100 rpm: | SAE | DIN 6270B |
| Net | 120 hp (90 kW) | 90 kW |
| Gross | 128 hp (95 kW) | |

Net engine power is with standard equipment including air cleaner, exhaust system, alternator, and cooling fan, at standard conditions per SAE J1349 and DIN 6270B using No. 2-D fuel @ 35 API gravity. No derating is required up to 10 000 ft (3000 m) altitude. Gross power is without cooling fan.

Engine:

| | |
|---|---|
| John Deere 6-cylinder turbocharged diesel 6068T | |
| SAE net horsepower | 120 hp (89 kW) |
| Bore and stroke | 4.19 x 5 in. (106.4 x 127 mm) |
| Maximum net torque @ 1300 rpm | 375 lb-ft (509 Nm) (51.8 kg-m) |
| Piston displacement | 414 cu. in. (6.785 L) |
| Compression ratio | 16.8 to 1 |
| Lubrication | Pressure system with full flow filters |
| Cooling | Pressurized with thermostat and controlled bypass |
| Fan | Blower |
| Dual-stage aspirated air cleaner with restriction indicator | Dry |
| Electrical system | 24 volt with alternator |
| Batteries (two 12-volt) cold cranking capacity at 0°F (-18°C) | 625 amps |
| Reserve capacity | 160 minutes each |

Transmission:

| | |
|----------------|---|
| Splitter drive | Pressure-lubricated helical gears drive both transmissions, main hydraulic pump, winch drive shaft and auxiliary pump drive |
| Drive | Dual-Path, fully automatic, infinitely variable hydrostatic transmissions |
| Speeds | Infinite from 0 to 6.5 mph (0 to 10.5 km/h) forward and reverse |

Steering

Fully modulated, infinitely variable pedal steering for live power turns and counterrotation. No need for steering clutches or steering brakes.

Brakes:

| | |
|---------|---|
| Service | Hydrostatic |
| Parking | Wet-disk brakes are automatically applied when engine is stopped, or manually applied with center foot pedal during normal operation. |

Hydraulic System (open center):

| | |
|----------|---|
| Pressure | 2250 psi (15 514 kPa) |
| Filter | 10 micron filter in return line with bypass |
| Pump | Gear, 54 gpm (204) L/min @ rated engine speed |

Tracks:


| | |
|--------------------------|--|
| Track shoes each side | 40 |
| Shoe width | |
| Standard | 15 in. (381 mm) |
| Wide track | 21 in. (533 mm) |
| Ground contact area | |
| Standard | 2724 sq. in. (17 575 cm ²) |
| Wide track | 3814 sq. in. (24 600 cm ²) |
| Ground pressure | |
| Standard | 11.9 psi (82 kPa) (0.8 bar) |
| Wide track | 8.8 psi (59 kPa) (0.6 bar) |
| Minimum ground clearance | 14 in. (356 mm) |
| Track gauge | |
| Standard | 64 in. (1.63 m) |
| Wide track | 70 in. (1.78 m) |

Hydraulic Cylinders:

| | Bore | Stroke |
|----------------------|-----------------------|--------------------|
| Boom | 5.50 in. (140 mm) | 32 in. (813 mm) |
| Bucket | 4.50 in. (114 mm) | 21.52 in. (547 mm) |
| Boom cylinder rods | 3.75 in. (95 mm) dia. | |
| Bucket cylinder rods | 2.25 in. (57 mm) dia. | |

| | |
|--|------------------------|
| SAE Operating weight w/ROPS | 32 400 lb (14 696 kg) |
| SAE Operating weight w/wide track and w/ROPS | 33 600 lb. (15 240 kg) |

755B CRAWLER LOADER



T7227AB(CV)

A—10 ft 3.7 in. (3.14 m)
B—18 ft 6.5 in. (5.65 m)
C—4.2 in. (107 mm)

D—9 ft 4.0 in. (2.84 m)
E—11 ft 11 in. (3.63 m)
F—45°
G—3 ft 11 in. (1.19 m)

TX,115,DH973 -19-16MAR92

T7227AB -JUN-12MAR90

0002
3

755B GENERAL SPECIFICATIONS

Specifications and design are subject to change without notice. Whenever applicable, specifications are in accordance with SAE standards. Except where otherwise noted, these specifications are based on a unit with a 2.25 cu yd (1.7 m³) bucket with teeth, roll-over protective canopy, four counterweights, full fuel tank, 175 (80 kg) operator and standard equipment.

| | | |
|--------------------------------|-----------------|------------------|
| Rated Power @ 2100 rpm: | SAE | DIN 6270B |
| Net | 140 hp (104 kW) | 104 kW |
| Gross | 148 hp (110 kW) | |

Net engine power is with standard equipment including air cleaner, exhaust system, alternator, and cooling fan, at standard conditions per SAE J1349 and DIN 6270B using No. 2-D fuel @ 35 API gravity. No derating is required up to 10 000 ft (3000 m) altitude. Gross power is without cooling fan.

Engine:

| | | |
|---|---|-------------|
| John Deere 6-cylinder turbocharged diesel 6068T | | |
| SAE net horsepower | 140 hp (104 kw) | |
| Maximum net torque @ 1300 rpm | 420 lb-ft (570 Nm) | (58.1 kg-m) |
| Compression ratio | 16.8 to 1 | |
| Bore and stroke | 4.19 x 5 in. (106.4 x 127 mm) | |
| Piston displacement | 414 cu. in. (6.785 L) | |
| Lubrication | Pressure system with full flow filters | |
| Cooling | Pressurized with thermostat and controlled bypass | |
| Fan | Blower | |
| Dual-stage aspirated air cleaner with restriction indicator | Dry | |
| Electrical system | 24 volt w/alternator | |
| Batteries (two 12-volt) cold cranking capacity at: | | |
| 0°F (-18°C) | 625 amps | |
| Reserve capacity | 160 minutes each | |

Transmission:

| | |
|----------------|---|
| Splitter drive | Pressure-lubricated helical gears drive both transmissions, main hydraulic pump, winch drive shaft and auxiliary pump drive |
| Drive | Dual-Path, fully automatic, infinitely variable hydrostatic transmissions. |
| Speeds | Infinite from 0 to 6.7 mph (0 to 10.8 km/h) forward and reverse |

Steering:

Fully modulated, infinitely variable pedal steering for live power turns and counterrotation. No need for steering clutches or steering brakes.

Brakes:

| | |
|---------|---|
| Service | Hydrostatic |
| Parking | Wet-disk brakes are automatically applied when engine is stopped, or manually applied with center foot pedal during normal operation. |

Hydraulic System (open center):

| | |
|----------|---|
| Pressure | 2500 psi (17 237 kPa) |
| Pump | Gear, 54 gpm (204 L/min) @ rated engine speed |
| Filter | 10 micron filter in return line w/bypass |

Tracks:

| | |
|--------------------------|--|
| Track shoes each side | 36 |
| Shoe width | |
| Standard | 17 in. (432 mm) |
| Wide track | 21 in. (533 mm) |
| Ground contact area | |
| Standard | 3173 sq. in. (20 472 cm ²) |
| Wide track | 3927 sq. in. (25 329 cm ²) |
| Ground pressure | |
| Standard | 11.4 psi (77 kPa) (1.2 bar) |
| Wide track | 9.5 psi (63 kPa) (0.6 bar) |
| Minimum ground clearance | 15.3 in. (389 mm) |
| Track gauge | |
| Standard | 66 in. (1.7 m) |
| Wide track | 70 in. (1.8 m) |

Hydraulic Cylinders:

| | Bore | Stroke |
|----------------------|-----------------------|--------------------|
| Boom | 5.50 in. (140 mm) | 32 in. (813 mm) |
| Bucket | 4.50 in. (114 mm) | 21.52 in. (547 mm) |
| Boom cylinder rods | 3.75 in. (95 mm) dia. | |
| Bucket cylinder rods | 2.25 in. (57 mm) dia. | |

| | |
|--|------------------------|
| SAE Operating weight w/ROPS | 36 150 lb (16 400 kg) |
| SAE Operating weight w/wide track and w/ROPS | 37 450 lb. (17 000 kg) |

655B AND 755B DRAIN AND REFILL CAPACITIES

| | U.S. | Metric |
|---|--------------------|---------|
| Cooling system | 7 gal | 26.5 L |
| Fuel tank | 73 gal | 276 L |
| Crankcase, including filter | 20 qt | 19 L |
| Splitter drive | 6 qt | 5.7 L |
| Inner final drive (655B) (each side) | 5 gal | 19 L |
| Inner final drive (widetrack) (each side) | 7.25 gal | 23.6 L |
| Outer final drive (each side) | 3.25 gal | 13.25 L |
| Hydraulic reservoir | 27.5 gal | 106 L |
| Hydrostatic transmission reservoir | 23 gal | 87 L |

T82,CRSP,AG -19-05JAN94

0002
5

0002
6

HARDWARE TORQUE SPECIFICATIONS












Check cap screws and nuts to be sure they are tight. If hardware is loose, tighten to torque shown on the following charts unless a special torque is specified.

T82,SKMA,AT -19-29.JAN92

0003
1

UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES

0003
2

| | | | | | | | |
|-----------------------------|---------|--|---|---|--|--|--|
| SAE Grade and Head Markings | NO MARK | 1 or 2 ^b  | 5  | 5.1  | 5.2  | 8  | 8.2  |
| | NO MARK | 2  | 5  | 5  | 8  | 8  | |

TS1162 -19-04/MAR91

| Size | Grade 1 | | | | Grade 2 ^b | | | | Grade 5, 5.1, or 5.2 | | | | Grade 8 or 8.2 | | | |
|-------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|
| | Lubricated ^a | | Dry ^a | | Lubricated ^a | | Dry ^a | | Lubricated ^a | | Dry ^a | | Lubricated ^a | | Dry ^a | |
| | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft |
| 1/4 | 3.7 | 2.8 | 4.7 | 3.5 | 6 | 4.5 | 7.5 | 5.5 | 9.5 | 7 | 12 | 9 | 13.5 | 10 | 17 | 12.5 |
| 5/16 | 7.7 | 5.5 | 10 | 7 | 12 | 9 | 15 | 11 | 20 | 15 | 25 | 18 | 28 | 21 | 35 | 26 |
| 3/8 | 14 | 10 | 17 | 13 | 22 | 16 | 27 | 20 | 35 | 26 | 44 | 33 | 50 | 36 | 63 | 46 |
| 7/16 | 22 | 16 | 28 | 20 | 35 | 26 | 44 | 32 | 55 | 41 | 70 | 52 | 80 | 58 | 100 | 75 |
| 1/2 | 33 | 25 | 42 | 31 | 53 | 39 | 67 | 50 | 85 | 63 | 110 | 80 | 120 | 90 | 150 | 115 |
| 9/16 | 48 | 36 | 60 | 45 | 75 | 56 | 95 | 70 | 125 | 90 | 155 | 115 | 175 | 130 | 225 | 160 |
| 5/8 | 67 | 50 | 85 | 62 | 105 | 78 | 135 | 100 | 170 | 125 | 215 | 160 | 215 | 160 | 300 | 225 |
| 3/4 | 120 | 87 | 150 | 110 | 190 | 140 | 240 | 175 | 300 | 225 | 375 | 280 | 425 | 310 | 550 | 400 |
| 7/8 | 190 | 140 | 240 | 175 | 190 | 140 | 240 | 175 | 490 | 360 | 625 | 450 | 700 | 500 | 875 | 650 |
| 1 | 290 | 210 | 360 | 270 | 290 | 210 | 360 | 270 | 725 | 540 | 925 | 675 | 1050 | 750 | 1300 | 975 |
| 1-1/8 | 400 | 300 | 510 | 375 | 400 | 300 | 510 | 375 | 900 | 675 | 1150 | 850 | 1450 | 1075 | 1850 | 1350 |
| 1-1/4 | 570 | 425 | 725 | 530 | 570 | 425 | 725 | 530 | 1300 | 950 | 1650 | 1200 | 2050 | 1500 | 2600 | 1950 |
| 1-3/8 | 750 | 550 | 950 | 700 | 750 | 550 | 950 | 700 | 1700 | 1250 | 2150 | 1550 | 2700 | 2000 | 3400 | 2550 |
| 1-1/2 | 1000 | 725 | 1250 | 925 | 990 | 725 | 1250 | 930 | 2250 | 1650 | 2850 | 2100 | 3600 | 2650 | 4550 | 3350 |

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.


Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

^b Grade 2 applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. Grade 1 applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.

METRIC BOLT AND CAP SCREW TORQUE VALUES



| Size | Class 4.8 | | | | Class 8.8 or 9.8 | | | | Class 10.9 | | | | Class 12.9 | | | |
|------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|-------------------------|-------|------------------|-------|
| | Lubricated ^a | | Dry ^a | | Lubricated ^a | | Dry ^a | | Lubricated ^a | | Dry ^a | | Lubricated ^a | | Dry ^a | |
| | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft |
| M6 | 4.8 | 3.5 | 6 | 4.5 | 9 | 6.5 | 11 | 8.5 | 13 | 9.5 | 17 | 12 | 15 | 11.5 | 19 | 14.5 |
| M8 | 12 | 8.5 | 15 | 11 | 22 | 16 | 28 | 20 | 32 | 24 | 40 | 30 | 37 | 28 | 47 | 35 |
| M10 | 23 | 17 | 29 | 21 | 43 | 32 | 55 | 40 | 63 | 47 | 80 | 60 | 75 | 55 | 95 | 70 |
| M12 | 40 | 29 | 50 | 37 | 75 | 55 | 95 | 70 | 110 | 80 | 140 | 105 | 130 | 95 | 165 | 120 |
| M14 | 63 | 47 | 80 | 60 | 120 | 88 | 150 | 110 | 175 | 130 | 225 | 165 | 205 | 150 | 260 | 190 |
| M16 | 100 | 73 | 125 | 92 | 190 | 140 | 240 | 175 | 275 | 200 | 350 | 225 | 320 | 240 | 400 | 300 |
| M18 | 135 | 100 | 175 | 125 | 260 | 195 | 330 | 250 | 375 | 275 | 475 | 350 | 440 | 325 | 560 | 410 |
| M20 | 190 | 140 | 240 | 180 | 375 | 275 | 475 | 350 | 530 | 400 | 675 | 500 | 625 | 460 | 800 | 580 |
| M22 | 260 | 190 | 330 | 250 | 510 | 375 | 650 | 475 | 725 | 540 | 925 | 675 | 850 | 625 | 1075 | 800 |
| M24 | 330 | 250 | 425 | 310 | 650 | 475 | 825 | 600 | 925 | 675 | 1150 | 850 | 1075 | 800 | 1350 | 1000 |
| M27 | 490 | 360 | 625 | 450 | 950 | 700 | 1200 | 875 | 1350 | 1000 | 1700 | 1250 | 1600 | 1150 | 2000 | 1500 |
| M30 | 675 | 490 | 850 | 625 | 1300 | 950 | 1650 | 1200 | 1850 | 1350 | 2300 | 1700 | 2150 | 1600 | 2700 | 2000 |
| M33 | 900 | 675 | 1150 | 850 | 1750 | 1300 | 2200 | 1650 | 2500 | 1850 | 3150 | 2350 | 2900 | 2150 | 3700 | 2750 |
| M36 | 1150 | 850 | 1450 | 1075 | 2250 | 1650 | 2850 | 2100 | 3200 | 2350 | 4050 | 3000 | 3750 | 2750 | 4750 | 3500 |

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

0003
4

ADDITIONAL METRIC CAP SCREW TORQUE VALUES

N CAUTION: Use only metric tools on metric hardware. Other tools may not fit properly. They may slip and cause injury.

Check tightness of cap screws periodically. Torque values listed are for general use only. Do not use these values if a different torque value or tightening procedure is listed for a specific application.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.


Make sure fastener threads are clean and you properly start thread engagement. This will prevent them from failing when tightening.

Tighten cap screws having lock nuts to approximately 50 percent of amount shown in chart.

METRIC CAP SCREW TORQUE VALUES*

| Nominal Dia | T-Bolt | | H-Bolt | | M-Bolt | |
|-------------|--------|-------|--------|-------|--------|-------|
| | N·m | lb-ft | N·m | lb-ft | N·m | lb-ft |
| 8 | 29 | 21 | 20 | 15 | 10 | 7 |
| 10 | 63 | 46 | 45 | 33 | 20 | 15 |
| 12 | 108 | 80 | 88 | 65 | 34 | 25 |
| 14 | 176 | 130 | 137 | 101 | 54 | 40 |
| 16 | 265 | 195 | 206 | 152 | 78 | 58 |
| 18 | 392 | 289 | 294 | 217 | 118 | 87 |
| 20 | 539 | 398 | 392 | 289 | 167 | 125 |
| 22 | 735 | 542 | 539 | 398 | 216 | 159 |
| 24 | 931 | 687 | 686 | 506 | 274 | 202 |
| 27 | 1372 | 1012 | 1029 | 759 | 392 | 289 |
| 30 | 1911 | 1410 | 1421 | 1049 | 539 | 398 |
| 33 | 2548 | 1890 | 1911 | 1410 | 735 | 542 |
| 36 | 3136 | 2314 | 2401 | 1772 | 931 | 687 |

*Torque tolerance is ±10%.



T6873AA

T-Bolt



T6873AB

H-Bolt



T6873AC

M-Bolt

-UN-18OCT88

T6873AA

-UN-18OCT88


T6873AB

-UN-18OCT88

T6873AC

SERVICE RECOMMENDATIONS FOR 37° FLARE AND 30° CONE SEAT CONNECTORS

1. Inspect flare and flare seat. They must be free of dirt or obvious defects.
2. Defects in tube flare cannot be repaired. Overtightening a defective flared fitting will not stop leaks.
3. Align tube with fitting before attempting to start nut.
4. Lubricate male threads with hydraulic fluid or petroleum jelly.
5. Index angle fittings and tighten by hand.
6. Tighten fitting or nut to torque value shown on torque chart. Do not allow hoses to twist when tightening fittings.



STRAIGHT FITTING OR SPECIAL NUT TORQUE CHART*

| Thread Size | N·m | lb-ft |
|----------------|-----|-------|
| 3/8 - 24 UNF | 8 | 6 |
| 7/16 - 20 UNF | 12 | 9 |
| 1/2 - 20 UNF | 16 | 12 |
| 9/16 - 18 UNF | 24 | 18 |
| 3/4 - 16 UNF | 46 | 34 |
| 7/8 - 14 UNF | 62 | 46 |
| 1-1/16 - 12 UN | 102 | 75 |
| 1-3/16 - 12 UN | 122 | 90 |
| 1-5/16 - 12 UN | 142 | 105 |
| 1-5/8 - 12 UN | 190 | 140 |
| 1-7/8 - 12 UN | 217 | 160 |

*Torque tolerance is $\pm 10\%$.


0003
5
-JUN-18OCT88
T6234AC

0003
6

SERVICE RECOMMENDATIONS FOR O-RING BOSS FITTINGS


STRAIGHT FITTING

1. Inspect O-ring boss seat for dirt or defects.
2. Lubricate O-ring with petroleum jelly. Place electrical tape over threads to protect O-ring. Slide O-ring over tape and into O-ring groove of fitting. Remove tape.
3. Tighten fitting to torque value shown on chart.



ANGLE FITTING

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer contacts face of boss.
3. Turn fitting head-end counterclockwise to proper index (maximum of one turn).
4. Hold fitting head-end with a wrench and tighten locknut and back-up washer to proper torque value.



NOTE: Do not allow hoses to twist when tightening fittings.

TORQUE VALUE

| Thread Size | N·m | lb·ft |
|--------------|-----|-------|
| 3/8-24 UNF | 8 | 6 |
| 7/16-20 UNF | 12 | 9 |
| 1/2-20 UNF | 16 | 12 |
| 9/16-18 UNF | 24 | 18 |
| 3/4-16 UNF | 46 | 34 |
| 7/8-14 UNF | 62 | 46 |
| 1-1/16-12 UN | 102 | 75 |
| 1-3/16-12 UN | 122 | 90 |
| 1-5/16-12 UN | 142 | 105 |
| 1-5/8-12 UN | 190 | 140 |
| 1-7/8-12 UN | 217 | 160 |

NOTE: Torque tolerance is ± 10%.

04T,90,K66 -19-09DEC93

-JUN-18OCT88


T6243AE

-JUN-18OCT88

T6520AB

SERVICE RECOMMENDATIONS FOR FLAT FACE O-RING SEAL FITTINGS

1. Inspect the fitting sealing surfaces. They must be free of dirt or defects.
2. Inspect the O-ring. It must be free of damage or defects.
3. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
4. Push O-ring into the groove with plenty of petroleum jelly so O-ring is not displaced during assembly.
5. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place.
6. Tighten fitting or nut to torque value shown on the chart per dash size stamped on the fitting. Do not allow hoses to twist when tightening fittings.



0003
7
-JUN-18OCT88
T6243AD

FLAT FACE O-RING SEAL FITTING TORQUE


| Nominal Tube O.D. mm | O.D. in. | Dash Size | Thread Size in. | Swivel Nut | | Bulkhead Nut | |
|-------------------------|-------------|--------------|--------------------|------------|-------|--------------|-------|
| | | | | N·m | lb-ft | N·m | lb-ft |
| 6.35 | 0.250 | -4 | 9/16-18 | 16 | 12 | 5.0 | 3.5 |
| 9.52 | 0.375 | -6 | 11/16-16 | 24 | 18 | 9.0 | 6.5 |
| 12.70 | 0.500 | -8 | 13/16-16 | 50 | 37 | 17.0 | 12.5 |
| 15.88 | 0.625 | -10 | 1-14 | 69 | 51 | 17.0 | 12.5 |
| 19.05 | 0.750 | -12 | 1 3/16-12 | 102 | 75 | 17.0 | 12.5 |
| 22.22 | 0.875 | -14 | 1 3/16-12 | 102 | 75 | 17.0 | 12.5 |
| 25.40 | 1.000 | -16 | 1 7/16-12 | 142 | 105 | 17.0 | 12.5 |
| 31.75 | 1.250 | -20 | 1 11/16-12 | 190 | 140 | 17.0 | 12.5 |
| 38.10 | 1.500 | -24 | 2-12 | 217 | 160 | 17.0 | 12.5 |

NOTE: Torque tolerance is +15 -20%.

0003
8


SERVICE RECOMMENDATIONS FOR FLARED CONNECTIONS—STRAIGHT OR TAPERED THREADS

1. Inspect flare and flare seat. They must be free of dirt or obvious defects.
2. Defects in the tube flare cannot be repaired. Overtightening a defective flared fitting will not stop leaks.
3. Align the tube with the fitting before attempting to start the nut.
4. Lubricate the male threads with hydraulic fluid or petroleum jelly.
5. Index angle fittings and tighten by hand.
6. Tighten fitting or nut to torque value shown on the chart. Do not allow hoses to twist when tightening fittings.



T6873AE

Straight Thread



T6873AD

Tapered Thread

TORQUE CHART*

| Thread Size | Straight Thread** | | Tapered Thread | |
|-------------|-------------------|-------|----------------|-------|
| | N·m | lb·ft | N·m | lb·ft |
| 1/8 | 15 | 11 | | |
| 1/4 | 20 | 15 | 45 | 33 |
| 3/8 | 29 | 21 | 69 | 51 |
| 1/2 | 49 | 36 | 93 | 69 |
| 3/4 | 69 | 51 | 176 | 130 |
| 1 | 157 | 116 | 343 | 253 |
| 1-1/2 | 196 | 145 | 539 | 398 |
| 2 | 255 | 188 | 588 | 434 |


NOTE: If female thread is cast iron (control valves, brake valves motors, etc.), torque must be reduced approximately 10%.

*Torque tolerance is $\pm 10\%$.

**With seat face.

T6873AE -JUN-18OCT88
T6873AD -JUN-18OCT88

SERVICE RECOMMENDATIONS FOR INCH SERIES FOUR BOLT FLANGE FITTINGS



A—Sealing Surface

B—Split Flange

C—Pinched O-Ring

D—Single Piece Flange

1. Clean sealing surfaces (A). Inspect. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If defects cannot be polished out, replace component.
2. Install O-ring (and backup washer if required) into groove using petroleum jelly to hold it in place.
3. Split flange: Loosely assemble split flange (B) halves. Make sure split is centrally located and perpendicular to port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring (C).
4. Single piece flange (D): Place hydraulic line in center of flange and install cap screws. Flange must

be centrally located on port. Hand tighten cap screws to hold flange in place. Do not pinch O-ring.

5. Tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten two remaining cap screws. Tighten all cap screws as specified in the chart below.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT over tighten.


TORQUE CHART*

| Nominal Flange Size | Cap Screw Size | N-m | | lb-ft | |
|---------------------|----------------|-----|-----|-------|-----|
| | | Min | Max | Min | Max |
| 1/2 | 5/16-18 UNC | 20 | 31 | 15 | 23 |
| 3/4 | 3/8-16 UNC | 28 | 54 | 21 | 40 |
| 1 | 3/8-16 UNC | 37 | 54 | 27 | 40 |
| 1-1/4 | 7/16-14 UNC | 47 | 85 | 35 | 63 |
| 1-1/2 | 1/2-13 UNC | 62 | 131 | 46 | 97 |
| 2 | 1/2-13 UNC | 73 | 131 | 54 | 97 |
| 2-1/2 | 1/2-13 UNC | 107 | 131 | 79 | 97 |
| 3 | 5/8-11 UNC | 158 | 264 | 117 | 195 |
| 3-1/2 | 5/8-11 UNC | 158 | 264 | 117 | 195 |
| 4 | 5/8-11 UNC | 158 | 264 | 117 | 195 |
| 5 | 5/8-11 UNC | 158 | 264 | 117 | 195 |

*Tolerance ± 10%. The torques given are enough for the given size connection with the recommended working pressure. Torques can be increased to the maximum shown for each cap screw size if desired. Increasing cap screw torque beyond this maximum will result in flange and cap screw bending and connection failures.

0003
10

SERVICE RECOMMENDATIONS FOR METRIC SERIES FOUR BOLT FLANGE FITTING



A—Sealing Surface

B—Split Flange

C—Pinched O-Ring

D—Single Piece Flange

1. Clean sealing surfaces (A). Inspect. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If defects cannot be polished out, replace component.
2. Install the correct O-ring (and backup washer if required) into groove using petroleum jelly to hold it in place.
3. Split flange: Loosely assemble split flange (B) halves. Make sure split is centrally located and perpendicular to the port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring (C).
4. Single piece flange (D): Place hydraulic line in center of flange and install four cap screws. Flange must be centrally located on port. Hand tighten cap screws to hold flange in place. Do not pinch O-ring.

5. After components are properly positioned and cap screws are hand tightened, tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten two remaining cap screws. Tighten all cap screws as specified in the chart below.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT over tighten.

TORQUE CHART*

| Thread** | N·m | lb·ft |
|----------|-----|-------|
| M6 | 12 | 9 |
| M8 | 30 | 22 |
| M10 | 57 | 42 |
| M12 | 95 | 70 |
| M14 | 157 | 116 |
| M16 | 217 | 160 |
| M18 | 334 | 246 |
| M20 | 421 | 318 |

*Tolerance \pm 10%. The torques given are enough for the given size connection with the recommended working pressure. Increasing cap screw torque beyond these amounts will result in flange and cap screw bending and connection failures.

**Metric standard thread.

T6890EB -JUN-01MAR90

CHECK TRACK SHOE BOLT TORQUE—EXCEPT SPLIT MASTER LINK

Check track shoe screws periodically for tightness.

MINIMUM TORQUE

| | |
|------------|---------------------|
| 755B | 440 lb-ft (597 N·m) |
| 655B | 280 lb-ft (380 N·m) |

If cap screws check less than above specification, remove shoes and clean paint or other foreign material from chain and shoe mating surfaces.

Lubricate cap screws and assemble shoes.

CAP SCREW TORQUE SPECIFICATION

| | Initial Torque | Additional Turn |
|------|---------------------|-----------------|
| 755B | 220 lb-ft (298 N·m) | 1/3 turn (120°) |
| 655B | 120 lb-ft (163 N·m) | 1/3 turn (120°) |

T82,CRMA,FU -19-29APR86

0003
12

CHECK SPLIT MASTER LINK TRACK SHOE BOLT TORQUE

MINIMUM TORQUE

| | |
|------------|---------------------|
| 755B | 440 lb-ft (597 N·m) |
| 655B | 280 lb-ft (380 N·m) |

If cap screws check less than above specification, remove shoe and clean paint or other foreign material from chain and shoe mating surfaces.

Lubricate cap screw threads and bearing surface of cap screw head using PT569 John Deere NEVER-SEEZ® Lubricant or equivalent.

IMPORTANT: DO NOT use impact wrench to start master shoe cap screws to avoid cross-threading.


Use only the torque turn method described below when assembling master track shoe. This method provides the optimum tightness level for this critical area.

Install master shoe on master links and start cap screws by hand to avoid cross-threading.

Tighten master cap screws in a criss-cross sequence (A). Repeat sequence a second time. Use same tightening sequence for additional turns.

MASTER CAP SCREW TORQUE SPECIFICATIONS

| | Initial Torque | Additional Turn |
|------|---------------------|-----------------|
| 755B | 220 lb-ft (298 N·m) | 1/2 turn (180°) |
| 655B | 120 lb-ft (163 N·m) | 1/3 turn (120°) |



T96302 -UN-01NOV88

NEVER-SEEZ is a trademark of the Never-Seez Compound Corp.

02T,45,K7 -19-29APR86

CHECK OIL LINES AND FITTINGS

N CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.


If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

Check all oil lines, hoses and fittings regularly for leaks or damage. Make sure all clamps are in position and tight. Make sure hoses are not twisted or touching machine parts which are moving.

Tubing with dents may cause the oil to overheat. If you find tubing with dents, install new tubing immediately.

IMPORTANT: Tighten fittings as specified in torque chart.

When you tighten connections, use two wrenches to prevent bending or breaking tubing and fittings.



0003
13

-UN-23AUG88

X9811

-UN-24JAN89

T85401

T82,FLMA,AI -19-14MAR90

USE THE PERIODIC MAINTENANCE CHART

The chart and the operator's manual list all the service points and the procedures for maintaining the machine. Use them to check, and adjust your customer's machine.

T82,CRPD,GO -19-06MAR85

FUEL SPECIFICATIONS

Use ONLY clean, high-quality fuel.

Use Grade No. 2-D fuel above 4°C (40°F).

Use Grade No. 1-D fuel below 4°C (40°F).

Use Grade No. 1-D fuel for all air temperatures at altitudes above 1 500 m (5000 ft).

IMPORTANT: If fuel sulfur content exceeds 0.5 per cent, the engine oil drain interval must be reduced by 50 per cent (to 125 hours).

Use fuel with less than 1.0 per cent sulfur. If possible, use fuel with less than 0.5 per cent sulfur.

For maximum filter life, sediment and water should not be more than 0.10 per cent.

The cetane number should be 40 minimum. If you operate your machine where air temperatures are normally low or where altitudes are high, you may need fuel with a higher cetane number.

Cloud Point—For cold weather operation, cloud point should be 6°C (43°F) below lowest normal air temperature.

T82,BHFL,F -19-14MAR90

STORING FUEL

If there is a very slow turnover of fuel in the fuel tank or supply tank, it may be necessary to add a fuel conditioner to prevent water condensation. Contact your John Deere dealer for proper service or maintenance recommendations.

DX,FUEL -19-03MAR93

FUEL TANK

N CAUTION: Handle fuel carefully. If the engine is hot or running, do not fill the fuel tank. Do not smoke while you fill fuel tank or work on fuel system.

To avoid condensation, fill the fuel tank at the end of each day's operation. Capacity is 73 gal (276 L).

X,655B,DS5252 -19-10MAY94

DO NOT USE GALVANIZED CONTAINERS

IMPORTANT: Diesel fuel stored in galvanized containers reacts with zinc coating on the container to form zinc flakes. If fuel contains water, a zinc gel will also form. The gel and flakes will quickly plug fuel filters and damage fuel injectors and fuel pumps.

DO NOT USE a galvanized container to store diesel fuel.


Store fuel in:

- plastic containers.
- aluminum containers.
- specially coated steel containers made for diesel fuel.

DO NOT USE brass-coated containers: brass is an alloy of copper and zinc.

MX,FLBT,C -19-04JUN90

TRANSMISSION OIL



T7673AR -19-04-FEB92

Depending upon the expected air temperature range between oil changes, use oil viscosity shown on the temperature chart above.

The following oils are recommended:

John Deere HY-GARD® Transmission and Hydraulic Oils.


Engine oil (SAE 10W) meeting one or more of the following:

API Service CD/SF, CD/SE, CD/SD, CD/SC (MIL-L-2104D, MIL-L-2104C).

John Deere All Weather Hydrostatic Oil.

TX,45,RR,2161 -19-13FEB92

GREASE



T6722AA -19-27/JAN89

Depending on the expected air temperature range, use grease shown on chart above.

Greases recommended are:

- John Deere Moly High Temperature/EP Grease (Preferred)

- SAE Multipurpose Grease with Extreme Pressure (EP) performance and containing 3 to 5 per cent molybdenum disulfide


- SAE multi-purpose EP Grease

- Grease meeting MIL-G-10924C specifications may be used as arctic grease.

02T,45,C49 -19-04DEC91

WINCH OIL

0004
8



T7784AD -19-17JUN92

Depending upon the expected air temperature range between oil changes, use oil viscosity shown on the temperature chart above.

John Deere HY-GARD® Transmission and Hydraulic Oil is recommended because it is specifically formulated to provide optimum clutch engagement, and to provide maximum protection against mechanical wear, rust, corrosion, and foaming.

Engine oil may be used provided it meets the TO2 oil test and one or more of the following: API Service

CD/SF, CD/SE, CD/SD, CD/SC, CC/SF, CC/SE, CC/SD, CC/SC (MIL-L-2104D, MIL-L-2104C, MIL-L-46152B.)

You may also use oils that meet minimum John Deere Standard J20A and J20C or J20B and J20D.

Oil meeting MIL-L-5606A may also be used as an arctic oil.

TX,45,RR2426 -19-03AUG92

**Thank you very much
for your reading.**

Please Click Here

**Then Get More
Information.**