

5440 and 5460 Self-Propelled Harvesters



JOHN DEERE

TECHNICAL MANUAL 5440 and 5460 Self-Propelled Harvesters

TM1177 (01APR77) English

TM1177 (01APR77)

LITHO IN U.S.A.
ENGLISH



5440 AND 5460 SELF-PROPELLED HARVESTERS

Technical Manual TM-1177 (Apr-77)

CONTENTS

SECTION 10 - GENERAL

- Group 5 - Specifications
- Group 10 - Predelivery, Delivery, and After-Sale Services
- Group 15 - Tune-Up
- Group 20 - Lubrication
- Group 25 - Diagnosing and Testing Procedures
- Group 30 - Separation
- Group 35 - Torque Values and Special Tools

SECTION 20 - ENGINE

- Group 5 - General Information (6404A OEM Engine)
- Group 10 - Diagnosing Malfunctions (6404A)
- Group 15 - Cylinder Head, Valves, and Camshaft (6404A)
- Group 20 - Cylinder Block, Liners, Pistons, and Rods (6404A)
- Group 25 - Crankshaft, Main Bearings, and Flywheel (6404A)
- Group 30 - Lubrication System (6404A)
- Group 35 - Cooling System (6404A)
- Group 40 - Specifications, Torques, and Special Tools (6404A)
- Group 45 - General Information (6619A OEM Engine)
- Group 50 - Diagnosing Malfunctions (6619A)
- Group 55 - Cylinder Head, Valves, and Camshaft (6619A)
- Group 60 - Cylinder Block, Liners, Pistons, and Rods (6619A)
- Group 65 - Crankshaft, Main Bearings and Flywheel (6619A)
- Group 70 - Lubrication System (6619A)
- Group 75 - Cooling System (6619A)
- Group 80 - Specifications, Torques, and Special Tools (6619A)

SECTION 30 - FUEL SYSTEM

- Group 5 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Fuel Injection System
- Group 20 - Air Intake System
- Group 25 - Specifications, Torques, and Special Tools

SECTION 40 - ELECTRICAL SYSTEM

- Group 5 - General Information and Diagrams
- Group 10 - Delcotron Charging Circuit
- Group 15 - Delco-Remy Starting Circuit
- Group 20 - John Deere Starting Circuit
- Group 25 - Lighting and Miscellaneous Components
- Group 30 - Specifications and Special Tools

SECTION 50 - POWER TRAIN

- Group 5 - Diagnosing Malfunctions
- Group 10 - Hydrostatic Drive
- Group 15 - Transmission
- Group 20 - Differential
- Group 25 - Final Drive
- Group 30 - Power Rear Wheel Drive
- Group 35 - Specifications, Torques, and Special Tools

SECTION 60 - STEERING AND BRAKES

- Group 5 - Diagnosing Malfunctions
- Group 10 - Steering
- Group 15 - Brakes
- Group 20 - Specifications, Torques, and Special Tools

CONTENTS—Continued

SECTION 70 - HYDRAULIC SYSTEM

- Group 5 - General Information and Tests
- Group 10 - Diagnosing Malfunctions
- Group 15 - Reservoir
- Group 20 - Hydraulic Pump
- Group 25 - Hydraulic Valves
- Group 30 - Hydraulic Cylinders
- Group 35 - Reverse Knife Grinder Motor
- Group 40 - Breakaway Coupler
- Group 45 - Spout Control Motor
- Group 50 - Specifications and Torques

SECTION 80 - MACHINE FUNCTIONS

- Group 5 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Clutch
- Group 20 - Main Gear Case
- Group 25 - Fan and Spout
- Group 30 - Cutterhead, Knife Grinder, and Feed Rolls
- Group 35 - Augers
- Group 40 - Specifications, Torques, and Special Tools

SECTION 90 - OPERATOR'S CAB

- Group 5 - Pressurizer System
- Group 10 - Air Conditioning System
- Group 15 - Heater System
- Group 20 - Specifications, Torques, and Special Tools

SECTION 100 - HARVESTING UNITS

- Group 5 - 7-Foot Hay Pickup Unit
- Group 10 - Row Crop Units
- Group 15 - Corn Head Attaching Parts
- Group 20 - Mower Bar Unit
- Group 25 - Specifications and Torques

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

**Copyright© 1974
DEERE & COMPANY
Moline, Illinois
All rights reserved**

INTRODUCTION



Use FOS Manuals for Reference

This technical manual is part of a twin concept of service:

- **FOS Manuals—for reference**
- **Technical Manuals—for actual service**

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

Fundamentals of Service (FOS) Manuals cover basic theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise on-the-job service guides containing only the vital information needed for a specific machine.



When a technician should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.



Use Technical Manuals for Actual Service

Some features of this technical manual:

- *Table of contents at front of manual*
- *Exploded views showing parts relationship*
- *Photos showing service techniques*
- *Specifications grouped for easy reference*

This technical manual was planned and written for you—an experienced mechanic. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.

Because John Deere sells its products world-wide, U.S. units of measure are shown with their respective Metric equivalents throughout this operator's manual. These equivalents are the SI (International System) Units of Measure.


SAFETY AND YOU


AVOID FIRE HAZARDS



T27999N

INTRODUCTION

 This safety alert symbol identifies important safety messages in this manual and on the harvester. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.



T27504N

Be prepared if an accident or fire should occur. Know where the first aid kit and the fire extinguishers are located—know how to use them.


SERVICE AREA

Keep the service area clean and dry. Wet or oily floors are slippery. Wet spots can be dangerous when working with electrical equipment.

Make sure the service area is adequately vented. Periodically check the shop exhaust system for leakage. Engine exhaust gas is dangerous.

Be sure all electrical outlets and tools are properly grounded.

Use adequate light for the job at hand.



Don't smoke while refueling or handling highly flammable material.

Engine should be shut off when refueling.

Use care in refueling if the engine is hot.

Don't use open pans of gasoline or diesel fuel for cleaning parts. Good commercial, nonflammable solvents are preferred.

Provide adequate ventilation when charging batteries.

Don't check battery charge by placing metal objects across the posts.

Don't allow sparks or open flame near batteries.

Don't smoke near battery.


Never check fuel, battery electrolyte or coolant levels with an open flame.

Never use an open flame to look for leaks anywhere on the equipment.

Never use a open flame as a light anywhere on or around the equipment.

When preparing engine for storage, remember that inhibitor is volatile and therefore dangerous. Seal and tape openings after adding the inhibitor. Keep container tightly closed when not in use.

CLEANING THE HARVESTER



Always stop the engine before cleaning the harvester.

Keep the operator's platform clean. Do not use it as a storage area.

Keep the radiator screen free of foreign matter. Avoid a possible fire hazard.

Keep all equipment free of dirt and oil. In freezing weather, beware of snow and ice on ladder steps and operator's platform.

FLUIDS UNDER PRESSURE


Escaping fluid under pressure can have sufficient force to penetrate the skin, causing serious personal injury. Before disconnecting lines, be sure to relieve all pressure. Before applying pressure to the system, be sure all connections are tight and that lines, pipes and hoses are not damaged. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands, to search for suspected leaks.

If injured by escaping fluid, see a doctor at once. Serious infection or reaction can develop if proper medical treatment is not administered immediately.

Don't forget the hydraulic system or diesel fuel injection system may be pressurized! To relieve pressure, follow the instructions in this technical manual.

When checking hydraulic pressure, be sure to use the correct test gauge for the pressure in the particular system.

PERSONAL SAFETY



Always avoid loose clothing or any accessory—flopping cuffs, dangling neckties and scarves—that can catch in moving parts and put you out of work. Always wear your safety glasses while on the job.

Keep transmission and brake control units properly adjusted at all times. Before making adjustments, stop engine.

Before removing any housing covers, stop engine. Take all objects from your pockets which could fall into the opened housings. Don't let adjusting wrenches fall into opened housings.

Don't attempt to check belt tension while the engine is running.

Don't adjust the fuel system while the machine is in motion.

Before repairing the electrical system, or performing a major overhaul, make sure the batteries are disconnected.

Avoid working on equipment with the engine running. If it is necessary to make checks with the engine running, **ALWAYS USE TWO PEOPLE**—one, the operator, at the controls, the other checking where the operator can see the person. Also, put the transmission in neutral, set the brake, and apply any safety locks provided. **KEEP HANDS AWAY FROM MOVING PARTS.**

Use extreme caution in removing radiator caps, drain plugs, grease fittings, or hydraulic pressure caps.

Section 10 GENERAL

CONTENTS OF THIS SECTION

	Page		Page
GROUP 5 - SPECIFICATIONS		GROUP 20 - LUBRICATION	
Specifications	5-1	General Information	20-1
		Lubricants	20-2
GROUP 10 - PREDELIVERY, DELIVERY, AND AFTER-SALE SERVICES		GROUP 25 - DIAGNOSING AND TESTING PROCEDURES	25-1
Predelivery Service	10-1		
Torque Chart	10-8	GROUP 30 - SEPARATION	
Delivery Service	10-10	Operator's Cab	30-1
After-Sale Inspection	10-10	Operator's Platform	30-3
		Auger Assembly	30-3
GROUP 15 - TUNE-UP		Cutterhead and Feed Roll Assembly	30-4
General Information	15-1	Engine	30-5
Preliminary Engine Testing	15-1		
Engine Tune-Up	15-1	GROUP 35 - TORQUE VALUES AND SPECIAL TOOLS	
Final Engine Testing	15-3	Torque Values	35-1
Miscellaneous Testing	15-3	Special Tools	35-1

Group 5 SPECIFICATIONS

ENGINE

Horsepower:	
5440.....	178 (133 kW)* 150 (112 kW)**
5460.....	255 (190 kW)* 225 (168 kW)**
Type.....	6-cylinder, in-line valve- in-head, diesel, turbo- charged and inter-cooled
Bore and stroke	
5440.....	4.25 in. x 4.75 in. 108 mm x 121 mm
5460.....	5.12 in. x 5 in. 130 mm x 127 mm
Displacement	
5440.....	404 cu. in. (6620 cm ³)
5460.....	619 cu. in. 10143 cm ³)
Compression ratio	
5440.....	15.5 to 1
5460.....	15.4 to 1
Firing order.....	1-5-3-6-2-4
Valve clearance.....	Intake-0.018 in. (0.46 mm) Exhaust-0.028 in. (0.71 mm)
Injection pump timing.....	TDC
Engine Speeds	
Working speed.....	2100 rpm
Slow idle.....	800 rpm
Fast idle (Full load).....	2100 rpm
(No load).....	2300 rpm

LUBRICATION SYSTEM..... Full pressurized
with full-flow micronic oil
filter, water-cooled oil
cooler, and bypass valves
for filter and cooler.

*Factory observed net horsepower at flywheel less fan
measured at 85°F (30°C), 29.3 in. Hg. operating at
2100 rpm.

**Factory observed net horsepower at cutterhead
drive sheave operating at 2100 rpm.

FUEL SYSTEM:

Type.....	Direct injection
Filter.....	Two-stage with replaceable impregnated paper element.
Injection pump type.....	Multiple plunger, in line
Air cleaner.....	Dry element with self-cleaning precleaner and safety element

COOLING SYSTEM:

Type.....	Pressurized with centrifugal pump
Temperature control.....	Heavy-duty thermostats

ELECTRICAL SYSTEM:

Type.....	12-volt, negative grounded
Batteries.....	Two, 6-volt 87-plate 204- ampere-hour, 7D type, connected in series
Alternator:	
5440.....	12-volt, 72-amp capacity
5460.....	12-volt, 72-amp capacity

MAIN CLUTCH (Blower Fan and Cutterhead Drive):

Type.....	Over-center, dry, metallic button, adjustable
Number of disks.....	2
Diameter.....	12 in. (305 mm)
Actuated.....	Hand lever

TRANSMISSION:

Type.....	Automotive spur gear with four speeds. Transmission is equipped with neutral start switch.
-----------	--

FINAL DRIVE:

Type.....	Pinion and ring gear
-----------	----------------------

Ground Speeds In mph (kmh)* (2100 engine rpm)

Gear	2 Wheel Drive With 18.4-26 Tires	
	1st	0-1.64 (2.6)
2nd	0-3.77 (6.1)	
3rd	0-6.86 (11.0)	
4th	0-16.80 (27.0)	
Gear	Power Rear Wheel Drive With 18.4-26 Tires	
	1st	0-1.40 (2.3)
2nd	0-2.80 (4.5)	
3rd	0-4.35 (7.0)	
4th	0-6.95 (11.2)	

*Reverse Ranges: (Ground travel speeds are approximately one-half the forward range.)

Hydrostatic System (Ground Drive):

Pump:
 Type Variable displacement
 Sunstrand 23 Series
 Speed 2100 rpm
 Displacement 0-5.43 cu. in. (89 cm³)
 per revolution

Charge Pump:
 Type Gear
 Speed 2100 rpm
 Displacement 1.1 cu. in. (18.0 cm³)
 per revolution
 Flow rate 10 gpm (37.9 lpm) at 2100 rpm

Motor:
 Type Fixed displacement
 Sunstrand 23 Series
 Speed 0-2100 rpm
 Displacement 5.43 cu. in. (88.98 cm³)
 per revolution

Relief pressure 5000 psi (345 bar)
 (350 kg/cm²)
 Flow rate 49 gpm (185 lpm) at 2100 rpm

Hydraulic System (Machine Functions):

Type: Open-center, constant-flow system. Includes power steering, header lift, spout rotation, cutterhead reverse grinder drive, and breakaway coupler (Optional)

Pump Gear-type
 Relief pressure 2250 psi (155-bar)
 (158 kg/cm²)

Flow rate: Steering
 (Priority) 2.75 gpm (10.4 lpm)
 Total 11.25 gpm (42.6 lpm)
 Speed 2100 rpm

Steering:

Type Full power hydraulic

Tire Options:

Front Wheels: (10-ply rated) 18.4-26; 10 PR
 Rear Wheels: (6-ply rated,
 3-rib implement) 11.00-16; 6 PR
 Power rear wheel drive 11.2-24 (4-PR,
 cleat type)

Brakes:

Type: 12-inch (304.8 mm) hydraulically actuated shoe-type. Individual brakes controlled by separate pedals.

Cutterhead:

Type Helical
 Diameter 24 in. (609.6 mm)
 Width 22 in. (558.8 mm)
 Knives Nine, J-style, tungsten carbide edge
 Speed 850 rpm
 Drive Three matched C-section belts

Cutterhead Reverse Grinder:

Drive Hydraulic motor
 Speed 425 rpm

Blower:

Type Lagged Radial Paddle
 Diameter 32 in. (813 mm)
 Number of paddles 4
 Speed 1020 rpm

Augers:

Number 2
 Drive Chain from cutterhead
 Diameter 10 in. (254 mm)
 Speed 558 rpm
 Discharge Side flow to blower fan

Power Rear Wheel Drive (Optional):

Type Hydrostatic motor driven with planetary gear reduction in wheel hub, uses pressure oil from hydrostatic system
 Controls Solenoid operated control valves, by electric switch on console
 Planetary disconnect Hydraulic wet brake on ring gear releases when drive is disengaged

CAPACITIES:

Fuel tank	72 U.S. gals. (272.5 l)
Cooling system:	
5440	11 U.S. gals. (41.6 l)
5460	15 U.S. gals. (56.8 l)
Engine crankcase (including oil filter)	
5440	17 U.S. qts. (16.1 l)
5460	24 U.S. qts. (22.7 l)
Transmission	11 U.S. qts. (10.4 l)
Feed roll drive case	3 U.S. qts. (2.8 l)
Final drives (two)	8 U.S. qts. ea. (7.6 l)
Main gear case	10 U.S. qts. (9.5 l)
Hydraulic system (including oil lines and cylinders)	3 U.S. gals. (11.3 l)
with hydraulic outlet	5 U.S. gals. (19 l)
Hydraulic brake master cylinder	1 U.S. Pt. (0.5 l) (approx.)
Hydrostatic drive system (including lines and components) (add 4 gals. [15.1 l] to capacity if equipped with Power Rear Wheel Drive)	7 U.S. gals. (26.5 l)

OPERATOR'S CAB


Cab Glass	49 square feet (4.55 m ²)
Pressure Fans (Blower)	
Capacity	435 cubic feet (10.42 m ³) per minute
Filter	Removable, re-useable, dry-type, paper element; 37 x 6-1/8 x 2-3/16 in. (940 x 156 x 56 mm)
Heater	
Capacity	18,000 BTU 3000 cubic feet (8.50 m ³) per minute
Air conditioner	
Capacity	20,000 BTU 300 cubic feet (8.50 m ³) per minute
Refrigerant	Refrigerant 12
Filters	Removable, re-useable, urethane foam; one each in normal and maximum air recirculators.
Fuses:	
Electric Clutch	7.5 Amp.
Dome Light	7.5 Amp.
Windshield Wiper	7.5 Amp.
Pressurizer Fans (Blower)	30 Amp.
Lamps:	
Head	15 Amp.
Tail	15 Amp.
Warning	15 Amp.
Spout	15 Amp.

TIRE INFLATION PRESSURES:

Front Wheels	26 psi (1.8 bar) (1.8 kg/cm ²)
	Torque to 300 ft-lbs (407 Nm)
Rear Wheels	20 psi (1.4 bar) (1.4 kg/cm ²)
	Torque to 120 ft-lbs (163 Nm)
Pickup Gauge Wheels	30 psi (2.1 bar)
	(2.1 kg/cm ²)

WEIGHT:

5440 with cab and standard axle	11900 lbs (5398 kg)
5460 with cab and standard axle	12400 lbs (5625 kg)



E14178N

A—132.50 in. (3 366 mm)
 B—55.70 in. (1 415 mm)
 C—17.50 in. (445 mm)
 D—103.50 in. (2 629 mm) 5460
 90.50 in. (2 200 mm) 5440

E—187.30 in. (4 757 mm) 5460
 177.40 in. (4 674 mm) 5440
 F—224.75 in. (5 709 mm)
 G—28.10 in. (714 mm) 5460
 30.90 in. (763 mm) 5440
 H—127.00 in. (3 226 mm)

I—103.54 in. (2 630 mm)
 105.34 in. (2 676 mm) with Bulge
 J—110.00 in. (2 794 mm) MAX
 82.00 in. (2 083 mm) MIN
 K—106.20 in. (2 697 mm)
 L—48.50 in. (1 232 mm)

Fig. 1-Dimensions of 5440 and 5460 Self-Propelled Harvesters

Group 10

PREDELIVERY, DELIVERY AND AFTER-SALE SERVICES

TEMPORARY UNIT STORAGE

After receiving your unit from the factory and before putting the machine into temporary storage, perform the following checks.

For long term storage (over 30 days) information, consult your operator's manual.

1. Check battery electrolyte level and charge the battery, if necessary.
2. Check the level of coolant in the radiator. The coolant should be maintained at a level 2 inches (51 mm) above the baffle.
3. Fill the fuel tank.
4. Check crankcase oil level. Oil should be above bottom mark of dipstick after machine has been shut down for 10 minutes.
5. Relieve hydraulic pressure by stopping engine and operating control levers until system fails to respond.
6. Reduce shipping pressure of front tires to 26 psi (1.8 bar) (1.8 kg/cm²) and rear tires to 20 psi (1.4 bar) (1.4 kg/cm²).
7. Cover unit for protection and cleanliness.

PREDELIVERY SERVICE

Because of the shipping factors involved, plus extra finishing touches that are necessary to promote customer satisfaction, proper predelivery service is of prime importance to the dealer and the customer.

NOTE: A protective cover is placed over the muffler outlet to prevent turbocharger rotation during transit. Remove protective cover before unloading harvester. Reinstall protective cover before transporting the harvester to the customer if machine is to be moved at highway speeds.

After completing the factory-recommended dealer checks and services listed on the predelivery tag, remove the tag from the harvester and file it with the shop order for the job. The tag will certify that the harvester has received the proper predelivery service when that portion of the customer's John Deere Delivery Receipt is completed.

Use the following list when preparing a unit for delivery to the customer.

1. Pre-Cleaner




Fig. 1-Pre-cleaner


Check and clean pre-cleaner bowl.

Pre-cleaner checked and cleaned.

Yes _____

2. Air Cleaner

Check air cleaner restriction indicator lamp on instrument panel. If indicator shows red, check and clean both primary and safety filter elements. Replace elements, if necessary.




A—Outer Element
 B—Wing Nut
 C—Outer Element Cover
 D—Inner Element

Fig. 2-Air Cleaner

Air Cleaner checked Yes _____
 Filters Replaced Yes _____

3. Fuel Filters



A—Fuel Filters
 B—Drain Plugs

Fig. 3-Fuel Filters

Check fuel filters and drain any sediment that is present. (See Section 30)

Filters checked Yes _____
 Sediment present in filters Yes _____

4. Batteries

Check battery electrolyte level. If distilled water is not available, use clean soft water. Avoid use of hard water. Remove foreign material from top of battery and coat terminals with petroleum jelly. Clean vent holes in battery caps.

IMPORTANT: Never add water to battery in freezing weather unless engine is to be run long enough (2 or 3 hours) to assure mixing of water and electrolyte.

Check battery connection.
 Punch date code on battery.

Battery Connections checked Yes _____
 Water added Yes _____

5. Fuel Tank





Fig. 4-Fuel Tank Filler Cap

Check the fuel gauge. If fuel gauge indicates a low supply of fuel, fill the tank (arrowed). Fuel tank capacity is 72 U.S. gals (273 l).

Fuel tank level Full 1/2 Full Empty

6. Fuel Tank Sump



A—Fuel Shut Off Valve
B—Fuel Tank
C—Sump Drain Cock

Fig. 5-Fuel Tank Sump

IMPORTANT: Sediment will settle over extended periods of transport or storage.

Open the sump drain cock. Allow fuel to drain out for approximately three seconds to allow moisture and sediment to drain out.

NOTE: Fuel tank sump drain is located on the bottom of the fuel tank.

Fuel sump drained Yes _____

7. Radiator





Fig. 6-Radiator Filler Cap

CAUTION: Remove the radiator filler cap only when the coolant temperature is below the boiling point. Then loosen the cap slightly to the stop to relieve pressure before removing the cap completely.

Check the level of coolant in the radiator. Coolant should be maintained at a level 2 inches (51 mm) above the baffle. Add permanent type antifreeze if cold weather is anticipated.

Radiator coolant level checked Yes _____
Coolant or antifreeze added Yes _____

8. Crankcase Oil Level




A—Dipstick
B—Oil Filler Cap

Fig. 7-Crankcase Oil Level

Check crankcase oil level with machine on level ground and engine off. If oil level is at or below bottom mark on dipstick, add sufficient oil of the proper viscosity and type specified on page 10-20-2 to bring oil level to between marks on dipstick. Do not operate engine with oil level below the bottom mark.

Crankcase oil level checked Yes _____
Oil added, if any _____ qts (l)

9. Alternator-Fan Belt Tension



A—Cap Screw

B—Belts

Fig. 8-Alternator-Fan Belt Tension

Check the tension on the alternator and fan belts.

The belts should have 1-inch (25 mm) flex when 25 pounds (111 N) of force is applied to the belt midway between the two pulleys.

IMPORTANT: Do not pry on rear alternator housing as this may damage the alternator.

Alternator belt tension checked
Fan belt tension checked

Yes _____
Yes _____

10. Check Air Intake Hoses




Fig. 9-Air Intake Hose

Check clamps on hose which connect air cleaner and turbocharger tube. Tighten hose clamps where necessary to prevent dirt from entering engine. Inspect hose for cracks.

Connections checked Yes _____

11. Check and Adjust Engine Speeds

Check engine speeds and adjust if necessary.


NOTE: Engine should be at operating temperature for the following adjustments.

See Section 30 for complete speed adjustment coverage.

Engine speeds checked Yes _____

12. Parking Brake

Adjusting Parking Brake



A—Loosen Cable


B—Tighten Cable

Fig. 10-Brake Lever

Release the parking brake lever and push lever downward as far as possible.

At the lower end of cable (B, Fig. 11.), pull the cable out of the cable housing (A) as far as possible; then, pull on equalizer (E) until brakes just start to actuate. A 1/8-inch (3 mm) space (C) should exist between the cable nut (D) and the equalizer (E).

If correct space does not exist, thread cable nut (D) on or off cable (B) until the space is correct.




A—Cable Housing
 B—Cable
 C—1/8-In. (3 mm)
 D—Cable Nut
 E—Equalizer

Fig. 11-Parking Brake Adjustment

Tighten or loosen cable by twisting lever handle in the proper direction (as shown, in Fig. 10) until lever actuation will cause sufficient braking for parking. At the proper adjustment, approximately 30 pounds (133 N) pull will be required to lock the brakes.

IMPORTANT: Damage to the brake linkage will result if the lever handle is tightened to the extent that excessive pull is required to lock the brakes.

Adjusting the Parking Brake Horn Switch



A—Nuts
 B—Switch Button
 C—Pin

Fig. 12-Adjusting Parking Brake Horn Switch

Whenever the parking brake is disengaged, make certain the warning horn is off. If horn is not off, adjust the following:

Adjust nuts (A) until the switch button (B) contacts the parking brake lever pin (C) when the lever is disengaged.

Parking brake checked Yes _____
 Horn switch checked Yes _____

13. Check Light Operation

Check operation of the following lights.





Fig. 13-Turn Signal Switch



E12680

Fig. 14-Light Switch

All Lights checked Yes _____

14. Check Transmission Shifting

The harvester has four speed ranges. The gearshift lever is used to shift transmission into desired range.


CAUTION: Make certain the gearshift lever and speed range control lever are in neutral position before starting engine.

IMPORTANT: Move the speed range control lever to neutral before attempting to shift gears. Do not attempt to shift gears "on-the-go."

Transmission operational

Yes _____

15. Indicator Lamps and Gauges




- A—Alternator Lamp
- B—Oil Indicator Lamp
- C—Air Restriction Lamp
- D—Water Temperature Gauge
- E—Fuel Gauge
- F—Tachometer

Fig. 15-Indicator Lamps and Gauges

Air Restriction Indicator

The red lamp in the restriction indicator will glow whenever the air cleaner element is dirty and needs servicing.

Alternator Indicator




E13472

Fig. 16-Alternator Indicator Lamp

This alternator lamp glows when the alternator is not charging. If the lamp goes on while the engine is running, stop engine and determine cause. Operation of this light is checked by turning the key to the "IGNITION" position with the engine stopped.

IMPORTANT: If indicator lamp glows when both switch and engine are "OFF", disconnect battery cables (negative cable first) then see section 40.

Oil Indicator



E 7713

Fig. 17-Oil Indicator Lamp

If the oil indicator lamp glows when engine is running, stop engine immediately and determine cause. The lamp will glow even though engine isn't running if the switch is turned to "IGNITION."

IMPORTANT: If indicator lamp glows when both switch and engine are "OFF", disconnect battery cables (negative cable first) then see section 40.

Water Temperature Gauge

This gauge indicates coolant temperature. Normal operating temperature is 180°F (82°C) to 200°F (93°C) (indicated by white band on dial). If temperature is 220°F (104°C) or above (indicated by red band on dial), stop engine and determine cause. At approximately 225°F (107°C) the automatic high-temperature warning device will activate the horn. Stop operation at once and determine cause of overheating.

IMPORTANT: If horn activates while harvester is operating and temperature gauge needle is in red band on dial, stop harvester and let engine run at idle speed. Check for cause of overheating. Failure to do so will result in serious engine damage.

Fuel Gauge

The fuel gauge indicates the quantity of fuel in the fuel tank. Fuel tank capacity is 72 gallons (273 l).

Gauges and Indicators Operational Yes _____

16. Checking Tire Pressure and Wheel Torques

Check the air pressure in all the tires with an accurate gauge having 1-pound (0.45 kg) graduations.


IMPORTANT: All tires must be inflated to the same pressure.

Adjust pressure in tires to the following specifications:

- Front Wheels 26 psi
(1.8 bar) (1.8 kg/cm²)
Torque to 300 ft-lbs (407 Nm) (41 kgm)
- Rear Wheels 20 psi
(1.4 bar) (1.4 kg/cm²)
Torque to 90 ft-lbs (122 Nm) (12 kgm)
- Pickup Gauge Wheels 30 psi
(2.1 bar) (2.1 kg/cm²)

17. Hydraulic Brakes

Check brake operation.



1—Brake Lock Position for Both Brakes
2—Brake Lock Position for Single Brake

Fig. 18-Brake Pedals

Brakes operational Yes _____

CHECK ALL GREASE FITTINGS AND FLUID LEVELS

Check all grease fittings for proper lubrication. Grease if necessary. See the operators manual.

CAUTION: To avoid possible injury, and to insure best results, always stop engine operation and lower all units to the ground before lubricating.

Grease fittings lubricated and fluids checked Yes _____

18. Steering

Start the engine and operate the steering wheel. Steering should be free and easy with engine running.

Steering operational Yes _____

19. Accessible Hardware Torque Values

Check all accessible bolts and nuts for proper tightness. If hardware seems loose, tighten it to the proper torque. The table below gives correct torque values for various bolts and cap screws. Most hardware used is high-strength (note dashes on hex. heads).

RECOMMENDED TORQUE IN FT-LBS (Nm) COARSE AND FINE THREADS			
Bolt Diameter	Plain Head	Three Dashes	Six Dashes
1/4	Not used	10 (14)	14 (19)
5/16	Not used	20 (27)	30 (41)
3/8	Not used	35 (47)	50 (68)
7/16	35 (47)	55 (75)	80 (108)
1/2	55 (75)	85 (115)	120 (163)
9/16	75 (102)	130 (176)	175 (237)
5/8	105 (142)	170 (230)	240 (325)
3/4	185 (251)	300 (407)	425 (576)
7/8	160 (217)	445 (603)	685 (929)
1	250 (339)	670 (908)	1030 (1396)
1-1/8	330 (447)	910 (1234)	1460 (1979)
1-1/4	480 (651)	1250 (1695)	2060 (2793)

E11318

Fig. 19-Torque Chart

The types of bolts and cap screws are identified by head markings as follows:

Plain Head: regular machine bolts and cap screws.

3-Dash Head: tempered steel high-strength bolts and cap screws.

6-Dash Head: tempered steel extra high-strength bolts and cap screws.

Machine bolts and cap screws 7/8-inch and larger are sometimes formed hot rather than cold, which accounts for the lower torque.

All accessible hardware torqued Yes_____

20. Check Main Clutch Operation




Fig. 20-Main Drive Clutch Lever

Place gearshift lever in desired gear range. Engage feedroll drive lever before engaging main drive clutch.

In normal operation the main clutch should be used to start and stop the harvesting unit and feedrolls. The machine should then be permitted to clean out prior to disengaging main clutch.

The feedroll drive clutch should be disengaged only if plugging or an emergency situation occurs. Disengage main drive clutch before re-engaging feedroll drive clutch. This prevents damage to the feedroll drive clutch components.

IMPORTANT: Do not use the feedroll drive clutch for convenience. For example, traveling across windrows with cutterhead still running but harvesting unit not. Either disengage main clutch or leave harvester operating.

IMPORTANT: The main clutch should normally be engaged when the engine is running below half speed. However, when material is in the machine, it is necessary to engage the clutch at full engine speed to prevent plugging.

Move the main clutch lever forward over-center, engaging the main clutch to operate the fan and cutterhead. This will also engage the feed rolls and harvesting unit, since the feed roll and harvesting unit drive lever is already engaged. Check to see that all components are running freely.

IMPORTANT: Always engage main clutch lever firmly. Do not hesitate while engaging clutch or damage to clutch may occur.

Main clutch operates properly Yes_____

Thank you very much for your reading. Please Click Here. Then Get COMPLETE MANUAL. NO WAITING



NOTE:

If there is no response to click on the link above, please download the PDF document first and then click on it.

21. Check Feed Roll Shift Lever





Fig. 21-Feed Roll Shift Lever

This lever allows forward drive and reversing of the feed rolls and harvesting unit. To engage the feed rolls and harvesting unit, move lever forward for normal feeding and rearward to reverse direction of the feed rolls and harvesting unit.

Feed roll shift lever operates properly Yes_____

22. Check Hydrostatic Drive Operation and Header Lift Lever



A—Header Lift Lever

B—Hydrostatic Drive Lever

Fig. 22-Drive and Spout Levers

Hydrostatic Drive Lever

This lever, along with the transmission, controls the ground speed. To move forward, push lever forward. To move rearward, raise lever and move lever rearward.

Header Lift Lever

The header lift lever allows complete movement of the cutterhead and harvesting unit from the operator's seat. To raise the head pull lever rearward. To lower the head push the lever forward.

Levers operate properly Yes_____

23. General Checks

Make the following general checks of the harvester before delivery.

All moving parts are working freely.

Cutterhead knives are properly adjusted.

Feed roll drive chain idler is adjusted.

Grinder stone tightened against stone door. Strip coating has been removed from stone shaft.

Make sure all slip clutches will slip.

Discharge spout cap control cable properly installed.

After pickup, row-crop, corn head unit, stalker or mower bar has been installed, run harvester for one-half hour and make sure bearings are not heating.

Tighten accessible nuts and cap screws.

Clean harvester and touch up paint.

24. Final Check

The final predelivery procedure is the overall clean-up of the unit. Make the unit LOOK like a new machine with the proper touch-up of chipped paint and a good wash job. Deliver to the customer a machine he will be proud to own.

DELIVERY SERVICE

A thorough discussion of the operation and service of a new harvester at the time of delivery helps to assure complete customer satisfaction. Proper delivery should be an important phase of a dealer's program. A portion of the John Deere Delivery Receipt emphasizes the importance of proper delivery service.

Many complaints have arisen simply because the owner was not shown how to operate and service his new harvester properly. Enough time should be devoted, at the customer's convenience, to introducing the owner to his new harvester and explaining to him how to operate and service it.

IMPORTANT: Install a cover over muffler outlet if hauling harvester to customer. This will prevent damage to the turbocharger caused by air passing through the turbocharger and rotating it without lubrication when the engine is stopped.

The following procedure is recommended before the service technician and owner complete the delivery acknowledgments portion of the delivery receipt.

Using the harvester operator's manual as a guide, be sure that the owner understands these points thoroughly:

1. Controls and instruments.
2. How to start and stop the engine.
3. The importance of the break-in period.
4. All functions of the hydraulic system.
5. All functions of hydrostatic system.
6. The operation of the feed roll shift lever.
7. Point out the slip clutches and the importance of proper adjustment.
8. Advise the customer of the proper procedure for using the sharpening stone and importance of maintaining proper shear bar-to-cutterhead knife adjustment.
9. Explain the advantages of using the correct recutter screen for special crop-operating conditions and the desired product.
10. Advise the customer of the optional attachments that are available for special crop and operating conditions.
11. The importance of lubrication and periodic services.
12. The importance of safety.

After explaining and demonstrating the above features, have the owner sign the delivery receipt and give him the operator's manual.

AFTER-SALE INSPECTION

The purchaser of a new John Deere harvester is entitled to a free inspection within the warranty period after the equipment has been "run in". The terms of this after-sale inspection are outlined on the back of the John Deere Delivery Receipt.

The purpose of this inspection is to make sure that the customer is receiving satisfactory performance from his harvester. At the same time, the inspection should reveal whether or not the harvester is being operated, lubricated, and serviced properly.

If the recommended after-sale service inspection is followed, the dealer can eliminate a needless volume of service work by preventing minor irregularities from developing into serious problems later on. This will promote strong dealer-customer relations and present the dealer an opportunity to answer questions that may have arisen during the first few days of operation. During the inspection service, the dealer has the further opportunity of promoting the possible sale of other new equipment.

The following inspection program is recommended within the first 100 hours of harvester operation.

Cooling System

1. Check Radiator Coolant Level





Fig. 23-Radiator Filler Cap

CAUTION: Remove the filler cap only when the coolant temperature is below the boiling point. Then loosen the cap slightly to the stop to relieve pressure before removing the cap completely.

Check the level of coolant in the radiator. Coolant should be maintained at a level 2-inches (51 mm) above the baffle. Add permanent type antifreeze if cold weather is anticipated.

Radiator coolant level checked Yes _____
Coolant or antifreeze added Yes _____

2. Clean Radiator Core



A—Air-Conditioner Condenser Core
B—Hydraulic Oil Cooler
C—Main Gear Case Cooler Core
D—Radiator Core

Fig. 14-Radiator Core

Pull screen off frame by removing two bolts. Clean and straighten bent fins on the air-conditioner condenser core (A), hydraulic oil cooler (B), main gear case cooler core (C on 5460 only), and radiator core (D). Remove all chaff, dirt, and foreign material from the radiator screen and replace it.

IMPORTANT: Horn will blow when radiator screen becomes clogged with dirt and causes engine overheating. Stop harvester, idle engine, and clean screen. Do not shut off engine.


Radiator core cleaned Yes _____

3. Hoses and Connections

Check all hoses and connections for leaks.

Fuel System


1. Remove water and foreign material from sediment bowl and fuel tank.



A—Sediment Bowl

B—Fuel Filters

Fig. 25-Fuel System



A—Fuel Shut-Off Valve

C—Sump Drain Cock

B—Fuel Tank

Fig. 26-Fuel Tank Sump and Shut-Off