


**John Deere
544C
Loader**



TECHNICAL MANUAL

**John Deere Dubuque Works
TM-1228 (Feb-84)**



LITHO IN U.S.A.

544C LOADER TECHNICAL MANUAL TM-1228 (FEB-84)

SECTION AND GROUP CONTENTS

SECTION I—GENERAL INFORMATION

- Group I—Cap Screw Torque Values
- Group II—Introduction and Safety Information
- Group III—General Specifications
- Group IV—Lubrication

SECTION 01—WHEELS

- Group 0110—Powered Wheels and Fastenings

SECTION 02—AXLES AND SUSPENSION SYSTEMS

- Group 0200—Removal and Installation
- Group 0210—Differential or Bevel Drive
- Group 0225—Input Drive Shafts and U-Joints
- Group 0250—Axle Shafts, Bearings and Reduction Gears
- Group 0260—Hydraulic System

SECTION 03—TRANSMISSION

- Group 0300—Removal and Installation
- Group 0315—Controls
- Group 0325—Input Drive Shafts and U-Joints
- Group 0350—Gears, Shafts, Bearings and Power Shift Clutch
- Group 0360—Hydraulic System

SECTION 04—ENGINE

- Group 0400—Removal and Installation
- Group 0401—Crankshaft and Main Bearings
- Group 0402—Camshaft and Valve Actuating Means
- Group 0403—Connecting Rods and Pistons
- Group 0404—Cylinder Block

SECTION 04—ENGINE—Continued

- Group 0407—Oiling System
- Group 0408—Ventilating System
- Group 0409—Cylinder Head and Valves
- Group 0410—Exhaust Manifold
- Group 0413—Fuel Injection System
- Group 0414—Intake Manifold
- Group 0416—Turbocharger
- Group 0417—Water Pump
- Group 0419—Oil Cooler
- Group 0420—Fuel Filter
- Group 0421—Fuel Transfer Pump
- Group 0422—Starting Motor and Fastenings
- Group 0433—Flywheel, Housing and Fastenings

SECTION 05—ENGINE AUXILIARY SYSTEMS

- Group 0505—Cold Weather Starting Aids
- Group 0510—Cooling Systems
- Group 0515—Speed Controls
- Group 0520—Intake System
- Group 0530—External Exhaust Systems
- Group 0540—Mounting Frame
- Group 0560—External Fuel Supply Systems

SECTION 06—TORQUE CONVERTER

- Group 0651—Turbine, Gears, Shafts and Bearings

Continued on next page

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice. Wherever applicable, specifications and design information are in accordance with SAE and ICED standards.

Copyright© 1984
DEERE & COMPANY
Moline, Illinois
All Rights Reserved
A JOHN DEERE ILLUSTRATION
Previous Edition
Copyright© 1983 Deere & Company
Copyright© 1982 Deere & Company
Copyright© 1980 Deere & Company

T09:1228 01 180184

SECTION AND GROUP CONTENTS—Continued

SECTION 09—STEERING SYSTEM

- Group 0930—Emergency Steering
- Group 0960—Hydraulic System

SECTION 10—SERVICE BRAKES

- Group 1011—Active Elements
- Group 1015—Controls Linkage
- Group 1060—Hydraulic System

SECTION 11—PARKING-EMERGENCY BRAKES

- Group 1111—Active Elements
- Group 1115—Controls Linkage

SECTION 16—ELECTRICAL SYSTEMS

- Group 1671—Batteries, Support and Cables
- Group 1672—Alternator, Regulator and Charging System Wiring
- Group 1673—Lighting System
- Group 1674—Wiring Harness and Switches
- Group 1675—System Controls
- Group 1676—Instruments and Indicators

SECTION 17—FRAME, CHASSIS, OR SUPPORTING STRUCTURE

- Group 1740—Frame Installation
- Group 1746—Frame Bottom Guards
- Group 1749—Chassis Weights

SECTION 18—OPERATOR'S STATION

- Group 1800—Removal and Installation
- Group 1810—Operator Enclosure
- Group 1821—Seat and Seat Belt
- Group 1830—Heating and Air Conditioning

SECTION 19—SHEET METAL AND STYLING

- Group 1910—Hood or Engine Enclosure
- Group 1921—Grille and Grille Housing
- Group 1927—Fenders

SECTION 20—SAFETY, CONVENIENCE AND MISCELLANEOUS

- Group 2002—Mirror
- Group 2004—Horn and Warning Devices
- Group 2006—Cigar Lighter

SECTION 21—MAIN HYDRAULIC SYSTEM

- Group 2160—Hydraulic System

SECTION 31—LOADER

- Group 3102—Buckets
- Group 3115—Controls Linkage
- Group 3140—Frames
- Group 3160—Hydraulic System

SECTION 33—BACKHOE

- Group 3300—Removal and Installation
- Group 3301—Blades, Teeth and Shanks
- Group 3302—Buckets
- Group 3315—Controls Linkage
- Group 3340—Frames
- Group 3360—Hydraulic System

SECTION 90 - SYSTEM TESTING

- Group 9005—General Information—Seven Basic Steps of Diagnosis and Testing
- Group 9010—Engine
- Group 9015—Electrical System
- Group 9020—Power Train
- Group 9025—Hydraulic System
- Group 9031—Heating and Air Conditioning

SECTION 99—SPECIAL TOOLS

INDEX

INTRODUCTION AND SAFETY INFORMATION

INTRODUCTION

This technical manual is part of a twin concept of service.

FOS Manuals - for reference.

Technical Manuals - for actual service.

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise service guides for a specific machine. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.

Some features of this technical manual:

John Deere ILLUSTRATION format emphasizing more detailed pictures and a minimum use of words.

Detailed repair procedures outlined in individual section.

System diagnostic testing detailed in separate section.

Table of contents of all sections at the front of the manual and a listing of all groups and headings at the front of each section.

Special tools and specifications listed at the front of each group they are used in.


Special tools illustrated in numerical order at end of manual.

Alphabetical listing of all major components, specifications, and special tools.

General specifications, lubrication requirements, and a summation of safety rules.

This technical manual was planned and written for you - an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.



02A:X2253N, X2252N T09:1116 090281

SAFETY AND YOU


CAUTION: This safety symbol followed by the word "caution" identifies important safety messages in this manual and on the loader or compactor. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.



T27999N

02A:T27999 N T09:1102 160181


Be prepared if an accident or fire should occur. Know where the first aid kit and the fire extinguishers are located - know how to use them.



T27504N

02A:T27504 N T09:1103 160181

Wear safety equipment.



T73432

02A:T73432 T09:1104 160181

Wear fairly tight clothing.




T45672

02A:T45672 R T09:1105 160181



CAUTION: Escaping fluid under pressure can have sufficient force to penetrate the skin, causing serious injury. Before disconnecting lines, be sure to relieve pressure. Before applying pressure, be sure connections are tight and lines, pipes and hoses are not damaged. Use a piece of cardboard or wood, rather than hands, to search for leaks.

If injured by escaping fluid, see a doctor at once. Serious infection or reaction can develop if proper medical treatment is not administered immediately.



02A:T45794 T09:1117 050281

KEEP SHOP AND STORAGE AREA CLEAN

Maintenance area should be adequately vented.

Keep maintenance area clean and dry.

Store flammable materials in a cool and well-vented area out of reach of unauthorized personnel.



02A:T27508 N T09:1107 160181

FOLLOW SAFE WORKING CONDITIONS

Perform work on equipment only if authorized to do so.

Follow recommended procedures.

Do not service equipment while it is being operated or engine is running.

Always use two service technicians - one, the operator at the controls, the other checking within sight of the operator.

Keep hands away from moving parts.

Support all raised equipment.

Do not work under raised bucket.

Always lower bucket before working on it.


If machine is on an incline, block it securely.

Use hoisting equipment for lifting heavy parts.

Wear safety glasses when drilling, grinding or hammering metal.

Do not use open flame around machine.

X WRONG



02A:T32709 N, T49041 N T09:1108 190181

OBSERVE SERVICE PRECAUTIONS

Keep all equipment free of dirt and oil.

Remove oil, grease, mud, ice, or snow from floor of operator's compartment or steps.


Do not remove radiator filler cap until coolant temperature is below the boiling point. Then loosen cap slowly to relieve pressure before removing.

Check exhaust system periodically for excessive leakage.

Relieve hydraulic pressure before working on hydraulic system.

Use the correct test group when checking hydraulic pressure.

Discharge accumulators completely before recharging or servicing.




02A:T49043N T09:1114 090281

OBSERVE REPAIR PRECAUTIONS

Relieve hydraulic pressure before working on hydraulic system.

Disconnect batteries before repairing the electrical system or performing a major overhaul.

Securely block bucket before changing cutting edges. Wear gloves when working with sharp edges.



02A:T49047 N T09:1115 090281

SPECIAL TOOLS


NOTE: Order tools from your SERVICE-GARD™ Catalog, unless otherwise indicated.

Number	Name	Use
D-01182AA	Shop Stands	Supports the unit while removing differentials
or		
D-24206WK		

T09;020001 171280


FRONT DIFFERENTIAL AND AXLE SPECIFICATIONS

1. Nuts torque (600 ± 60 N·m) 445 ± 45 lb-ft



06A;T77458 T09;020002 030682


2. Cap screws torque (68 ± 7 N·m) 50 ± 5 lb-ft



06A;T77400 T09;020056 090281

REAR DIFFERENTIAL AND AXLE SPECIFICATIONS

1. Install shims to give an end play clearance of (0.03 to 0.46 mm) 0.001 to 0.018 in.




06A;T77394 T09;020004 030682

Removal and Installation


2. Cap screws and nuts torque

5/8 in.(325 N·m) 240 lb-ft
20 mm (680 ± 68 N·m) 500 ± 50 lb-ft



06A:T77459 T09:020005 030682


3. Cap screws torque (68 ± 7 N·m) 50 ± 5 lb-ft.



06A:T77402 T09:020057 110281


FRONT AXLE AND DIFFERENTIAL ASSEMBLY - PUT SHOP STANDS UNDER LOADER FRAME

1. Lift loader boom as high as possible. Put a support with a rated capacity of approximately (1772 kg) 3900 lbs. under bucket and boom.
2. Stop the engine.
3. Operate the steering valve, brake valve and loader control valve to release hydraulic pressure in the systems. Put loader control lever into float position.
4. Install lock bar (1).




06A:T75019 T09:020007 221280

5. Disconnect battery ground cables (1).



06A:T76321 T09:020058 110281

6. Remove bottom guard (if equipped).
7. Fasten a chain hoist (1) to the loader frame hooks and lift the front of the machine.
8. Put D-00182AA (shown) or D-24206WK Shop Stands (2) under loader frame. Lower machine onto shop stands.
9. Remove wheels (Group 0110).




06A:T77460 T09:020059 110281

DISCONNECT HYDRAULIC LINES AND DRIVE SHAFT

CAUTION: Escaping hydraulic oil under pressure can have sufficient force to penetrate the skin, causing serious injury. Before disconnecting lines, be sure to relieve pressure. Before applying pressure, be sure connections are tight and lines, pipes, and hoses are not damaged. Use a piece of cardboard or wood, rather than hands, to search for leaks.


If injured by escaping oil, see a doctor at once. Serious infection or reaction can develop if proper medical treatment is not administered immediately.

1. Disconnect hydraulic brake line (1) and differential lock return hose (2).



06A:T77461 T09:020011 240383


2. Disconnect differential lock inlet line (1).
3. Close all openings with caps and plugs to keep dirt from entering the hydraulic system.
4. Remove four cap screws (2) to disconnect drive shaft from input quill.



06A:T75216 T09:020012 240283


LOWER DIFFERENTIAL AND AXLE ASSEMBLY

1. Remove drain plug to drain approximately (22.5 L) 6 gal. of oil from differential.
2. Put a lifting strap (1) around each axle housing.




06A;T77462 T09;020013 030682

3. Put tension on straps and remove eight bolts and nuts.



06A;T77463 T09;020014 171280


4. Lower axle and differential as an assembly.



06A;T77464 T09;020015 171280

INSTALL DIFFERENTIAL AND AXLE ASSEMBLY


1. Lift axle and differential assembly in loader frame.
2. Install eight bolts, 16 washers and eight nuts (1). Tighten nuts to $(600 \pm 60 \text{ N}\cdot\text{m})$ $445 \pm 45 \text{ lb}\cdot\text{ft}$.



06A:T77463 T09:020016 171280


CONNECT DRIVE SHAFT AND HYDRAULIC LINES

1. Connect drive shaft and fasten with cap screws (2). Tighten cap screws to $(68 \pm 7 \text{ N}\cdot\text{m})$ $50 \pm 5 \text{ lb}\cdot\text{ft}$.
2. Connect differential lock inlet line (1).



06A:T75216 T09:020060 111083


3. Connect hydraulic brake line (1) and return hose (2).



06A:T77461 T09:020018 240283

REMOVE SHOP STANDS

1. Install wheels (Group 0110).
2. Lift loader frame with chain hoist (1) and remove shop stands (2).



06A:T77460 T09:020019 171280


FILL DIFFERENTIAL WITH OIL

1. Install drain plug.
2. Fill the front differential SLOWLY with recommended oil to fill plug level. See Section I, Group IV for the type of oil used. Let the unit stand for approximately one minute and check the differential oil level. Add more oil if necessary.
3. Connect battery cables, start the engine and lower boom and bucket assembly.
4. Bleed brake hydraulic system (Group 1060).

T09:020020 101183


**REAR AXLE AND DIFFERENTIAL ASSEMBLY
- PUT SHOP STANDS UNDER ENGINE
FRAME**

1. Lower all equipment to the ground.
2. Stop the engine.
3. Operate the steering valve, brake valve and loader control valve to release hydraulic pressure in the systems.
4. Install lock bar (1).




06A:T75019 T09:020024 171280

5. Disconnect battery ground cables (1).
6. Remove center bottom guard (if equipped).



06A:T78321 T09:020051 110281

7. Lift the rear of unit and put D-24206WK (shown) or D-01182AA Shop Stands under engine frame.
8. Put lifting straps around each axle housing and put equal tension on straps.
9. Remove wheels (Group 0110).



06A:T77465 T09:020026 171280


DISCONNECT BRAKE LINE

NOTE: View looking down left side of engine.



CAUTION: Escaping hydraulic oil under pressure can have sufficient force to penetrate the skin, causing serious injury. Before disconnecting lines, be sure to relieve pressure. Before applying pressure, be sure connections are tight and lines, pipes, and hoses are not damaged. Use a piece of cardboard or wood, rather than hands, to search for leaks.

If injured by escaping oil, see a doctor at once. Serious infection or reaction can develop if proper medical treatment is not administered immediately.




1—Brake Line

06A:T77466 T09:020027 221280


LOWER DIFFERENTIAL AND AXLE ASSEMBLY

1. Remove drain plug (1) to drain approximately (22.5 L) 6 gal. of oil from differential.



06A:T77467 T09:020028 171280


2. Remove four cap screws to disconnect rear differential drive line.



06A:T77468 T09:020029 171280


Removal and Installation

3. Remove four cap screws and nuts from front oscillating support.
4. Disconnect oscillating grease line (2) from fitting.




06A:T77469 T09:020030 171280

5. Disconnect oscillating pin grease line (1).




06A:T77470 T09:020031 171280

6. Remove four cap screws and nuts from rear support.



06A:T77472 T09:020032 172280


7. Lower axle and differential as an assembly.



06A:T77473 T09:020033 171280


INSTALL DIFFERENTIAL AND AXLE ASSEMBLY

1. Before installing differential assembly, remove O-ring (1).
2. Install rear support assembly with front thrust plate (2) on dowel pin. Install rear thrust plate (3) with straight edge of plate up. Grease grooves in thrust plates must face each other. DO NOT install any shims.



06A:T77474 T09:020034 030682


3. Lift axle and differential assembly in engine frame.



06A:T77473 T09:020035 171280


ADJUST DIFFERENTIAL AND AXLE ASSEMBLY

1. Install and tighten only two cap screws and nuts (1) in both front and rear support.
2. With a pry bar, move the differential and axle assembly as far forward as possible.



06A:T77475 T09:020036 221280


3. With a feeler gauge, measure the clearance (1) between the rear thrust plate and support.



06A:T77394 T09:020037 171280


Removal and Installation

4. Measure the thickness of feeler gauge blades.




06A:T77476 T09:020038 171280

5. Measure each shim separately to equal a shim pack thickness which will give an end play clearance of (0.03 to 0.46 mm) 0.001 to 0.018 in.



06A:T77477 T09:020039 030682


6. Lower differential and axle assembly and remove support.
7. Install O-ring (2) and shim pack (1). Install shims between rear thrust plate and support.
8. Install support.



06A:T77478 T09:020040 171280

FASTEN FRONT AND REAR SUPPORT

1. Install dowels (1) in rear support.
2. Put T43515 John Deere Loctite® retaining compound or an equivalent on mounting surface of support.



06A:T77479 T09:020041 221280

Loctite is a trademark of the Loctite Corp.

**Thank you very much for
your reading. Please Click
Here. Then Get COMPLETE
MANUAL. NO WAITING**




NOTE:

**If there is no response to
click on the link above,
please download the PDF
document first and then
click on it.**


Removal and Installation

3. Install dowels (1) in front support.
4. Make sure fitting (2) is positioned as shown.
5. Put T43515 John Deere Loctite retaining compound or an equivalent on mounting surface of support.




06A:T77480 T09:020042 221280

6. Lift differential and axle assembly under engine frame. Install cap screws, washers and nuts to fasten front support. Tighten 5/8 in. cap screws to (325 N·m) 240 lb-ft. Tighten 20 mm cap screws to (680 ± 68 N·m) 500 ± 50 lb-ft.



06A:T77481 T09:020043 030682


7. Install cap screws, washers and nuts to fasten rear support. Tighten 5/8 in. cap screws to (325 N·m) 240 lb-ft. Tighten 20 mm cap screws to (680 ± 68 N·m) 500 ± 50 lb-ft.



06A:T77472 T09:020044 030682

CONNECT DIFFERENTIAL DRIVE LINE AND OSCILLATING GREASE LINES


1. Connect rear differential drive line and fasten with cap screws. Tighten cap screws to (68 ± 7 N·m) 50 ± 5 lb-ft.



06A:T77468 T09:020062 110281


Removal and Installation

2. Connect the oscillating grease lines (1) on both front and rear supports.



06A:777470 T09:020046 171280

CONNECT BRAKE LINE




1—Brake Line

06A:777466 T09:020047 171280

REMOVE SHOP STANDS


1. Install wheels (Group 0110). Remove lifting straps.
2. Lift the rear of unit to remove shop stands.



06A:777465 T09:020048 171280

FILL DIFFERENTIAL WITH OIL

1. Install drain plug.
2. Fill the rear differential SLOWLY with recommended oil to fill plug level. See Section I, Group IV for the type of oil used. Let the unit stand for approximately one minute and check the differential oil level. Add more oil if necessary.
3. Bleed brake hydraulic system (Group 1060).
4. Install the center bottom guard (if equipped).



06A:T77467 T09:020049 080982