


# 535 Log Loader



## SERVICE MANUAL



For complete service information also see:


<b>POWERTECH® 8.1 L (6081)</b>	
Diesel Engines Repair .....	<b>CTM86</b>
<b>POWERTECH® 8.1 L (6081) Diesel</b>	
Engines Operation and Diagnostics .....	<b>CTM134</b>
Alternators and Starting Motors .....	<b>CTM77</b>

**John Deere Dubuque Works**  
**TM1876 (01DEC00)**

LITHO IN U.S.A.  
ENGLISH

## 0060 Component Locators


### 1. General Component Locator



24850


- |                             |                        |
|-----------------------------|------------------------|
| 1. Main Boom                | 8. Main Boom Cylinders |
| 2. Cab                      | 9. Jib Boom Cylinder   |
| 3. Hydraulic Tank Enclosure | 10. Stabilizer         |
| 4. Engine Enclosure         | 11. Heel Bar           |
| 5. Upper frame (Turntable)  | 12. Jib Boom           |
| 6. Swing Bearing            | 13. Grapple            |
| 7. Lower Frame              |                        |

## **2. Lower Frame Component Locator**



- |                              |                                  |
|------------------------------|----------------------------------|
| 1. Stabilizer Pad            | 6. Access Steps                  |
| 2. Stabilizer                | 7. Upper Stabilizer Cylinder pin |
| 3. Lower Frame (Base)        | 8. Stabilizer Pivot Pin          |
| 4. Swing Bearing             | 9. Lower Stabilizer Cylinder Pin |
| 5. Stabilizer Cylinder Cover | 10. Stabilizer Pad Pivot Pin     |

### 3. Upper Frame Component Locator




TJ302

1. Turntable Pedestal
2. Upper Frame
3. Hydraulic Tank
4. Engine Compartment Enclosure

5. Fuel Tank
6. Handrail
7. Access Steps




## 4. Cab Component Locator



TJ230

- |  |                                |
|--|--------------------------------|
| 12. Work Light (6 used)                  | 16. Antenna                    |
| 13. Speaker (2 used)                     | 17. Cab Air Recirculate Intake |
| 14. AM/FM Radio/Cassette Player (Option) | 18. Outside Air Intake         |
| 15. Air Conditioner/Heater Unit          |                                |


**5. Engine Component Locator**



TJ220

- |                             |                                  |
|-----------------------------|----------------------------------|
| 1. Engine, John Deere 8.1 L | 6. Pilot Pump                    |
| 2. Drive Coupling           | 7. Air Conditioner Compressor    |
| 3. Starter Solenoid         | 8. Turbocharger                  |
| 4. Starter Motor            | 9. Turbocharger Lubrication Line |
| 5. Engine Mount             | 10. Aftercooler                  |

## 5. Engine Component Locator




TJ219

- |                                  |   |
|----------------------------------|---|
| 1. Turbocharger                  | 8. Crankshaft Hub                       |
| 2. Turbocharger Lubrication Line | 9. Fuel Supply Pump                     |
| 3. Oil Fill Cap                  | 10. Throttle Actuator                   |
| 4. Oil Dipstick                  | 11. Oil Filter                          |
| 5. Coolant Outlet                | 12. Primary Fuel Filter/Water Separator |
| 6. Alternator                    | 13. Fuel Filter                         |
| 7. Coolant Inlet                 |   |



## 6. Hydraulic Component Locator



TJ229

- |  |                                    |
|--|------------------------------------|
| 1. Grapple Rotator   | 9. Hydraulic Return Filters        |
| 2. Grapple Open/close Cylinder                                 | 10. Hydraulic Tank                 |
| 3. Jib Boom Cylinder   | 11. Main Pump                      |
| 4. Stabilizer Cylinder   | 12. Swing Control Valve            |
| 5. Main Boom Cylinders (2 used)                                | 13. Pilot Pump                     |
| 6. Swing Motor (w/anti-cavitation and crossover relief valves) | 14. Lockout Valve                  |
| 7. Jib Boom Control Valve                                      | 15. Block Valve                    |
| 8. Main Boom Control Valve                                     | 16. Stabilizer Cylinder Lock Valve |


## 0070 Transporting the Log Loader

### 1. Transporting the Log Loader

See the Operator's Manual for procedures to transport the Log Loader.

**IMPORTANT:** This equipment is for OFF ROAD USE ONLY and is not intended for extended on-road use at speed.

**IMPORTANT:** Use chains or suitable straps to secure the booms, heel and grapple to a support cradle or grapple carrier as required during transport.

 **CAUTION:** Careless or inappropriate preparation of the loader for transport can result in accidents causing personal injury and equipment damage.

When transporting this equipment to alternative job sites, move this equipment ONLY in accordance with federal, state, and local regulations.

Regardless of the equipment configuration, height requirements MUST NOT exceed specified maximums.

## **1. Transporting the Log Loader**

BEFORE attempting to transport this equipment:

- Familiarize yourself with the actual dimensions of the equipment.
- Familiarize yourself with the planned transportation route and clearances on any overhanging obstructions.
- Familiarize yourself with road conditions on your planned transportation route.
- Familiarize yourself with posted speed recommendations for your transportation route and **DO NOT EXCEED THEM!**
- Close all doors, engine covers, and hydraulic valves.
- Verify that the transport trailer's tires are properly inflated.
- Verify that the transport trailer's air brake system is properly connected and fully operational.
- Properly secure all attachments, tools and other equipment.
- Verify that all clearance, brake, turn and tail lights are operational.
- Verify that the key has been removed from the control panel ignition switch.

## **0080 Repairs**

### **1. General Troubleshooting Techniques**

The troubleshooting procedures provided in the sections describe some problems that can be experienced with the various components or systems. While every effort has been made to list the most likely sources of problems, no guarantee of completeness is offered. Some causes produce more than one symptom or problem. The possible causes are arranged from the simplest, most likely to occur to the more complex, least likely to occur. In every instance a systematic approach to diagnostics is essential.

- Ensure that the correct operating procedure is being followed.
- Identify the problem as completely as possible.
- Check the simplest and obvious causes first.
- The solutions to most problems are simpler and less costly if acted on as soon as a problem is noted.

It may be necessary to periodically check or adjust certain systems or components. See the John Deere 535 Operator's Manual for more information.

See the component manufacturer's service manuals for more detailed information regarding specific components.

## **2. Welding Instructions**

When welding, there are a number of concerns to keep in mind:

Some parts must never be welded. These include the loader fastening bolts, the control valves and any hydraulic pipes.

Some parts must not be welded without specific instructions from the component manufacturer. These include castings and cylinder loops.

Do not weld any other parts to castings, boom ends, cylinder fastening lugs, corners of box girders nor the cab. Do not drill any holes in the cab.

When welding connect the ground wire as close to the welding point as possible. The welding current must never pass through bearings, joints, electrical equipment nor hydraulic systems.

**IMPORTANT: Before welding, turn the electrical system Master Switch to OFF and disconnect the battery ground wire.**

## **3. Hydraulic Hoses Inspection and Replacement**

All hydraulic lines (hoses) are sized to carry the required flow rates at velocities low enough to eliminate excessive pressure losses and heat generation.

Replacement hoses should not be a smaller diameter. They must be of a pressure rating equal to the one being replaced.

Correct hose length and routing is essential to ensure performance and hose life. When replacing hoses ensure that the type of hose and fittings and the length of hose are exactly the same as those being replaced.

Kinked, stretched, twisted or pinched hoses will not provide good performance or a long service life.

## 4. Inspection Check Lists

**John Deere**

Inspection Checklist - Page 1 of 2

**535 Log Loaders**

Machine Model	Serial Number
---------------	---------------

Dealer \_\_\_\_\_ Address \_\_\_\_\_ Dealer Code \_\_\_\_\_

Owner \_\_\_\_\_ Address \_\_\_\_\_  
 Street/Route No. City/Town State/Province Zip Code

Machine Hours \_\_\_\_\_ Into Service Date \_\_\_\_\_  
 Month Day Year

Record the following Serial Numbers

Engine _____	Grapple _____
Main Pump _____	Main Control Valve _____
Pilot Motor _____	Jib Control Valve _____
Swing Motor _____	Swing Bearing _____
Cab _____	Swing Gearbox _____

PLEASE MARK [X] FOR INSPECTION BEING REPORTED

Important: All information must be completed to validate the warranty on the unit identified herein.

- |                                     |                                    |                                    |
|-------------------------------------|------------------------------------|------------------------------------|
| Check/Add as Required [ ]           | Check for Leaks at Op Temp [ ]     | Check Torque:                      |
| 1. Engine Oil [ ]                   | Hydraulic System [ ]               | 35. Engine Mounting Bolts [ ]      |
| 2. Engine Coolant [ ]               | 15. Suction Hoses and Fittings [ ] | 36. Pump/Motor Mounting Bolts [ ]  |
| 3. Hydraulic Oil [ ]                | 16. Hyd Lines/Hoses/Fittings [ ]   | 37. Cab mounting Bolts [ ]         |
| 4. Swing Gearbox Oil [ ]            | 17. Hyd Pump/Motor/Filters [ ]     | 38. Radiator Mounting Bolts [ ]    |
| 5. Windshield Washer Fluid [ ]      | 18. Oil Cooler & Fittings [ ]      | 39. All Drain Plugs [ ]            |
|                                     | 19. Cylinders & Fittings [ ]       | 40. Boom Cyl Pins, Bolts, Nuts [ ] |
| Inspect/Lubricate as Required       | Engine:                            | 41. Swing Bearing Bolts [ ]        |
| 6. Boom Pins and Bushings [ ]       | 20. Oil Filter [ ]                 | 42. Swing Reducer Bolts [ ]        |
| 7. Grapple Pins and Bushings [ ]    | 21. Cooling System [ ]             | 43. Swivel Mounting Bolts [ ]      |
| 8. Cylinder pins and Bushings [ ]   | 22. Fuel Lines & Filters [ ]       | Miscellaneous:                     |
| 9. Stabilizer Pins and Bushings [ ] | 23. Air Intake System [ ]          | 44. Electrical Wiring [ ]          |
| 10. Swing Bearing [ ]               | 24. Exhaust System [ ]             | & Connections                      |
| 11. Swing Brg and Pinion Teeth [ ]  | 25. Coolant Filter [ ]             | 45. Heater/Air Conditioner [ ]     |
| Check/Adjustment as Required        | Check Welding & Workmanship        | Operation                          |
| 12. Eng. Throttle/Stop Linkage [ ]  | 26. Base Frame [ ]                 | 46. Recirculation Fan [ ]          |
| 13. Engine 'V' Belt Tension [ ]     | 27. Stabilizers [ ]                | 47. Lights [ ]                     |
| 14. Fan/Shroud Clearance [ ]        | 28. Turntable & Upper [ ]          | 48. Windshield Wiper & Washer [ ]  |
|                                     | 29. Booms [ ]                      | 49. Horn [ ]                       |
|                                     | 30. Cab [ ]                        | 50. Any Loose Bolts, Leaks, [ ]    |
|                                     | Check Safety Equipment             | Abnormalities                      |
|                                     | Installed & Operational            |                                    |
|                                     | 31. Fire Extinguisher [ ]          |                                    |
|                                     | 32. Seat Belts [ ]                 |                                    |
|                                     | 33. Horn [ ]                       |                                    |
|                                     | 34. Decals [ ]                     |                                    |

TJ228

# 4. Inspection Check Lists

**John Deere**

Inspection Checklist - Page 2 of 2

**535 Log Loaders**

Machine Model	Serial Number
---------------	---------------

Machine Hours \_\_\_\_\_

RECORD THE INFORMATION BELOW:

Engine Operating Temperature: \_\_\_\_\_  
 Engine Oil Pressure (Hot) at Idle: \_\_\_\_\_  
 Engine RPM (Max. No Load): \_\_\_\_\_  
 Engine Coolant Antifreeze For: \_\_\_\_\_  
 Hydraulic Oil Temperature: \_\_\_\_\_  
 Battery Voltage: \_\_\_\_\_  
 Electrolyte Specific Gravity: \_\_\_\_\_

Hydraulic Valve Settings:	Main	Work Ports
Main Boom Relief:	_____	_____
Jib Boom Relief:	_____	_____
Swing Circuit Relief:	_____	_____
Stabilizer Relief:	_____	_____
Pilot Pump Relief:	_____	_____

Remarks:

Dealer Representative Signature \_\_\_\_\_

Date \_\_\_\_\_

TJ227

## **5. Extended Storage**


The following steps must be taken whenever the machine is to be stored or removed from service for an extended period of time.

- Scrupulously clean the entire unit.
- Seal any exposed hydraulic lines.
- Lubricate all fittings.
- Fill the fuel tank.
- Top-off the hydraulic reservoir.
- Protect exposed cylinder rods with a weather retardant coating.
- Protect the unit to minimize weather damage (indoor storage, tarps, etc.).



## 1000 Power Unit

### 1. Description and Operation



TJ226

The primary source of power for the machine is a turbocharged and aftercooled, 8.1 liter six cylinder John Deere engine. The engine is mounted in the engine compartment enclosure at the left rear corner of the upper frame.

Engine output drives the main pump providing hydraulic flow for machine functions.

The air conditioning compressor and alternator are belt driven from the engine crankshaft hub.

The power unit as a group includes the engine, the main pump drive coupling, the fuel system, the radiator and cooling system, the air intake system and the exhaust system.

## **1. Description and Operation**

See Section 1100, Engine, and Section 9800, General Machine Specifications, for engine specifications.

See Section 1100, Engine, for information regarding engine troubleshooting.

See Section 1300, Engine Mounting, for procedures replace engine mounts and procedures to remove and install the engine.

See Section 1400, Fuel System, for information on the fuel lines, level sensor and fuel/water separator and for procedures to remove and install the fuel tank.

See Section 1500, Cooling System for procedures service the cooling system and to remove and install the radiator.

See Section 1700, Air Intake System, for information on the air cleaner.

See Section 1800, Exhaust System, for procedures to remove and install the muffler.

ALSO:

See Section 2000, Hydraulics, and Section 2940, Filler and Tilt Pumps, for information on the engine enclosure tilt system.

See Section 2130, Pilot Pump, for information on the pilot pump.


See Section 2950, Hydraulic Cooling, for information on the oil cooler.

See Section 5500, Heater/Air Conditioner Unit, for information on the A/C compressor and condenser and the cab heater hose arrangement.

## 1100 Engine

### 1. Description and Operation

#### 1.1 General



TJ206


The primary source of power for the machine is a turbocharged and aftercooled, 8.1 liter six cylinder John Deere engine. The engine is mounted in the engine compartment enclosure behind the operator cab.

Consult the Operator's Manual for operation and maintenance procedures.

Consult the John Deere Component Technical Manual CTM86, for detailed procedures to service and repair the engine.

# 1. Description and Operation

## 1.1 General




TJ220

- |                             |                                  |
|-----------------------------|----------------------------------|
| 1. Engine, John Deere 8.1 L | 6. Pilot Pump                    |
| 2. Drive Coupling           | 7. Air Conditioner Compressor    |
| 3. Starter Solenoid         | 8. Turbocharger                  |
| 4. Starter Motor            | 9. Turbocharger Lubrication Line |
| 5. Engine Mount             | 10. Aftercooler                  |

## 1. Description and Operation

### 1.1 General




TJ219

- |                                  |   |
|----------------------------------|---|
| 1. Turbocharger                  | 8. Crankshaft Hub                       |
| 2. Turbocharger Lubrication Line | 9. Fuel Supply Pump                     |
| 3. Oil Fill Cap                  | 10. Throttle Actuator                   |
| 4. Oil Dipstick                  | 11. Oil Filter                          |
| 5. Coolant Outlet                | 12. Primary Fuel Filter/Water Separator |
| 6. Alternator                    | 13. Fuel Filter                         |
| 7. Coolant Inlet                 |   |

## 1. Description and Operation

### 1.2 Gauges and Warning Indicators



TJ225

- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>1. Tachometer and Hourmeter Gauge</li> <li>2. Engine Temperature, Voltmeter, Oil Pressure and Fuel Level Gauges</li> <li>3. Air Filter Restriction Indicator</li> <li>4. Low Engine Oil Pressure Indicator</li> </ul> | <ul style="list-style-type: none"> <li>5. Hydraulic Oil Filter Bypass Indicator</li> <li>6. Low Hydraulic Oil Level Warning Indicator</li> <li>7. Low Engine Coolant Level Warning Indicator</li> <li>8. High Engine Coolant Temperature Indicator</li> <li>9. Alarm Shutoff/Lights Check Switch</li> </ul> |
|--|---|

A number of engine conditions are indicated on gauges and warning lights on the console in the cab.

## 1. Description and Operation

### 1.2 Gauges and Warning Indicators

#### Indicators

Six indicator lamps are located on the instrument panel, to the operator's right in the cab. When illuminated, these lamps indicate that critical limits have been reached for the following:

- Hydraulic oil filter restriction
- Air filter restriction
- High engine coolant temperature
- Low engine oil pressure
- Low engine coolant level
- Low hydraulic oil level

A central alarm buzzer will sound when any of the warning lamps are lit.

#### Gauges

With the engine idling and at normal operating temperature, readings should be as follows:

Tachometer . . . . .	850 rpm
Engine Coolant Temperature . . .	84°C (202°F)
Oil Pressure . . . . .	30 psi or minimum
Voltmeter . . . . .	12 to 14 Volts

**IMPORTANT:** During full-load operation the indicated oil pressure must be in the 40 to 70 psi range. Pressure below this range indicates the possibility of severe equipment damage.

## 1. Description and Operation

### 1.3 Engine Enclosure Raising and Lowering

**⚠ CAUTION:** Whenever engine compartment is open, always position engine enclosure prop rod in the locked position. Failure to do so can lead to personal injury or death.


*NOTE:* Engine enclosure can be raised and lowered by using either the engine enclosure raise/lower switch located on the side of the operator's control panel or the manual pump lever located on the engine enclosure control valve.

1. Raise engine enclosure.
2. Insert prop rod (1) into oval slot (2) located on engine enclosure hood bottom frame.

*NOTE:* Ensure that prop rod safety stop (3) is seated into oval slot on engine enclosure frame.

**IMPORTANT:** Damage to the engine enclosure will occur if hood is lowered with prop rod not properly stowed.

3. Prior to lowering engine enclosure, stow prop rod in support storage bracket (4) located on radiator frame.



VIEW LOOKING AFT

TJ289

1. Prop Rod
2. Oval Slot
3. Safety Stop
4. Storage Bracket



**Thank you very much for your reading. Please Click Here. Then Get COMPLETE MANUAL. NO WAITING**



**NOTE:**

**If there is no response to click on the link above, please download the PDF document first and then click on it.**

## 1. Description and Operation


### 1.4 Engine Enclosure Hand Pump Operation

**⚠ CAUTION:** Whenever engine compartment is open, always position engine enclosure prop rod in the locked position. Failure to do so can lead to personal injury or death.

*NOTE:* In the event of a non-operational engine or dead batteries, the engine enclosure can be raised and lowered by using the manual pump lever located on the engine enclosure control valve.

*NOTE:* Jack handle is normally located behind the operator's seat in the cab.


1. Insert jack handle into manual pump lever (1) mechanism on engine enclosure control valve (3).
2. To raise engine enclosure, push in and turn clockwise knurled knob (2) located on engine enclosure control valve solenoid.
3. Pump jack handle to raise enclosure.
4. To lower engine enclosure, pull out and hold knurled knob (2) while continuing to pump jack handle.
5. Remove and properly stow jack handle.



1. Pump Lever
2. Knurled Knob
3. Control Valve

## 1. Description and Operation

### 1.5 Engine Throttle




The throttle control is a dual-action, spring-return, rocker switch located on the instrument panel. The switch is used for the adjustment and maintenance of engine speed (rpm) during loader operation.

Press right side to increase engine speed (rabbit).

Press left side to decrease engine speed (turtle).

Release when the desired engine speed is attained.

See Section 3000, Electrical, for details on the wiring.



An electrically operated actuator (A) mounted on right side of engine block controls throttle linkage movement.

Adjust throttle by loosening bracket mounting hardware (B) and re-positioning actuator bracket (C).

Throttle actuator must be allowed to extend fully to the end of its travel.

See engine specifications for correct idling rpm.

TJ218