


John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST833498 - CYLINDER HEAD HOUSING

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER5801363172	HOUSING	1		
2	ER5801363175	GASKET	4		
3	ER0504273002	PLUG	4	M12 X 1.5	
4	ER0016673835	BOLT	9	M8 X 30	




Copyright © 2017 Deere & Company. All Rights Reserved.

John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST833502 - CYLINDER HEAD COVER

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER5801526315	COVER	1		
2	ER5801446795	GASKET	1		
3	ER0016591725	BOLT	7	M6 X 40	
4	ER0016598325	BOLT	3	M8 X 100	






Copyright © 2017 Deere & Company. All Rights Reserved.

John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST833602 - DRIVE BELT / PULLEY


KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER5801363585	PULLEY	1		
2	ER0016675835	BOLT	6		
3	ER5801380424	SPACER	1		
4	ER5801440074	V-BELT	1		





John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST833482 - FLYWHEEL HOUSING

PART NO.	PART NAME	QTY	REMARKS		
ER0504180348	HOUSING	1			
ER0016678034	BOLT	6	M12 X 40		
ER0016673735	BOLT	2	M8 X 1.25 X 25	1	
ER0002995644	ADHESIVE	1			
ER0004895378	PLUG	1			
ER0017288480	O-RING	1			
	ER0504180348 ER0016678034 ER0016673735 ER0002995644 ER0004895378	ER0504180348 HOUSING ER0016678034 BOLT ER0016673735 BOLT ER0002995644 ADHESIVE ER0004895378 PLUG	ER0504180348 HOUSING 1 ER0016678034 BOLT 6 ER0016673735 BOLT 2 ER0002995644 ADHESIVE 1 ER0004895378 PLUG 1	ER0504180348 HOUSING 1 C	




0011507

John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST865021 - FLYWHEEL / MOUNTING PARTS, ENGINE

Je 2 cc. c	John 2000 Tall March 101 Tall						
KEY	PART NO.	PART NAME	QTY	REMARKS			
1	ER372511	FLYWHEEL	1	(PowrReverser™) 11"			
1	ER436582	FLYWHEEL	1	(Mechanical Transmission) 12"			
2	ER393149	SELF-LOCKING SCREW	8	M12 X 42.5			
3	ER021143	SCREW	6	M12 X 50			
4	ER021148	SCREW	2	M12 X 60			
5	ER021155	SCREW	2	M12 X 80			
6	ER021157	BOLT	2	M12 X 90			
7	ER022861	WASHER	12				
8	ER024502	PIN	1				
9	ER026017	BEARING	1	(Mechanical Transmission) 12"			
10	ER202960	DOWEL PIN	2				






Y040548


John Deere > Turf And Utility > TRACTOR > F5DFL413C - TRACTOR > 5075GV Tractor (Engine F5D) IT4 (Europe Edition) > 20 ENGINE > ST833620 - FUEL INJECTION PUMP

John Beere > Turn And Othing > TNACTOR > 30730V Tractor (Engine 1307) 114 (Edrope Edition) > 20 Engine > 31033020 TOLE Tryce Tol V Tolling						
KEY	PART NO.	PART NAME	QTY	REMARKS		
1	ER5801470100	FUEL INJECTION PUMP	1			
2	ER0504387506	GEAR	1			
3	ER5801470105	FUEL RAIL	1			
4	ER0504387341	FUEL LINE	1			
5	ER0504387346	FUEL LINE	1			
6	ER0017044725	NUT	3	M8 X 1.25		
7	ER0017094904	WASHER	3			
8	ER5801474163	VALVE	1			
9	ER0042553494	O-RING	1			
10	ER5801474160	SENSOR	1	(Pressure Sensor)		
11	ER5801555843	BRACKET	1			




John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST833491 - CYLINDER HEAD

J				
KEY	PART NO.	PART NAME	QTY	REMARKS
1	ER0504389002	CYLINDER HEAD	1	
2	ER0504162949	VALVE SEAT	4	
3	ER0004749397	GUIDE	8	STD
3	ER0004749398	GUIDE	8	DIA = + 0.1 mm
3	ER0004749399	GUIDE	8	DIA = + 0.2 mm
4	ER5801475385	STUD	8	M8 X 1.25
5	ER0016990970	PLUG	1	
6	ER0504254094	VALVE SEAT	4	
7	ER0016988301	PLUG	8	
8	ER0504387778	INTAKE VALVE	4	
9	ER0504387779	EXHAUST VALVE	4	
10	ER0504178119	CAP	8	
11	ER0004812347	SPRING	8	
12	ER0004780558	CAP	8	
13	ER0040101573	CAP	8	
14	ER0004819891	RETAINER	16	
15	ER0504081521	STUD	6	M15 X 1.5 X 193
16	ER0504081533	STUD	4	M12 X 1.5 X 162
17	ER5801450757	GASKET	1	TK = + 0.8 mm
17	ER5801450758	GASKET	1	TK = + 0.7 mm
18	ER0504387777	VALVE COVER	8	
19	ER0099435557	DOWEL PIN	1	
20	ER0016990670	PLUG	4	



John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST833621 - INJECTION NOZZLE

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER5801470098	ELECTRONIC UNIT INJECTOR	4		
2	ER0004899689	WASHER	4		
3	ER0504378841	BRACKET	4		
4	ER5801473742	STUD	4	M8 X 65	
5	ER0500353601	WASHER	4		
6	ER0017044735	NUT	4		
7	ER0008097971	CLAMP	4		






John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST833641 - FUEL LINES

John Beere's Tally and Gamey's Hotel OK's 30/304 Hactor (Engine 135) IT (Edrope Edition) 220 ENGINE 2310330 IT TOLL ENGLS						
KEY	PART NO.	PART NAME	QTY	REMARKS		
1	ER5801698739	VALVE	1			
2	ER0504332869	COVER	1			
3	ER0017316290	CLIP	1			
4	ER5801476218	FUEL LINE	1			
5	ER5801496365	FUEL LINE	1			
6	ER0504385537	FUEL LINE	1			
7	ER0504388781	FUEL LINE	1			
8	ER0504385539	FUEL LINE	1			
9	ER0016586725	BOLT	2	M8 X 30		
10	ER0016597925	BOLT	2	M8 X 14		
11	ER0504332889	GASKET	1			






John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST833506 - ROCKER ARM / SHAFT

PART NO.	PART NAME	QTY	REMARKS		
ER5801364420	SUPPORT	1			
ER5801364425	SHAFT	1			
ER0016987801	PLUG	2			
ER0099454296	SCREW	1			
ER0504389302	ROCKER ARM	4	(Intake)		
ER0504389297	ROCKER ARM	4	(Exhaust)		
ER0018139224	BOLT	10	M6 X 1.0 X 70		
	ER5801364420 ER5801364425 ER0016987801 ER0099454296 ER0504389302 ER0504389297	ER5801364420 SUPPORT ER5801364425 SHAFT ER0016987801 PLUG ER0099454296 SCREW ER0504389302 ROCKER ARM ER0504389297 ROCKER ARM	ER5801364420 SUPPORT 1 ER5801364425 SHAFT 1 ER0016987801 PLUG 2 ER0099454296 SCREW 1 ER0504389302 ROCKER ARM 4 ER0504389297 ROCKER ARM 4	ER5801364420 SUPPORT 1 ER5801364425 SHAFT 1 ER0016987801 PLUG 2 ER0099454296 SCREW 1 ER0504389302 ROCKER ARM 4 (Intake) ER0504389297 ROCKER ARM 4 (Exhaust)	






LX245611

John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST877144 - EXHAUST GAS RECIRCULATION

John Deere	John Deere > Turi And Utility > TRACTOR > F5DFL413C - TRACTOR > 50/5GV Tractor (Engine F5D) 114 (Europe Edition) > 20 Engine > 518//144 - EXHAUST GAS RECIRCULATION							
KEY	PART NO.	PART NAME	QTY	REMARKS				
1	ER5801958838	HEAT EXCHANGER	1					
2	ER5801669153	CHECK VALVE	1					
3	ER0504385412	CLIP	1					
4	ER5801596396	WATER TRAP	1					
5	ER0017281881	O-RING	3					
6	ER0018186570	CLIP	8					
7	ER5801385612	WATER TRAP	1					
8	ER0017289181	O-RING	1					
9	ER5801560222	HOSE FITTING	1					
10	ER0504341194	GASKET	3					
11	ER5801602826	BOLT	2					
12	ER0016598325	BOLT	3	M8 X 100				
13	ER0017044725	NUT	2	M8 X 1.25				
14	ER5801530821	HOSE	1					
15	ER0004798845	SCREW	3	LGTH = 103 mm				
16	ER5801602848	BOLT	2					
17	ER0018137825	BOLT	2	M6 X 16				



Copyright © 2017 Deere & Company. All Rights Reserved.

John Deere > Turf And Utility >TRACTOR >F5DFL413C - TRACTOR >5075GV Tractor (Engine F5D) IT4 (Europe Edition) >20 ENGINE >ST833568 - EXHAUST MANIFOLD

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	ER0504388669	EXHAUST MANIFOLD	1		
2	ER0504170332	GASKET	1		
3	ER0504294819	NUT	8		
4	ER0016729434	STUD	2	M8 X 25	
5	ER0500322677	NUT	2		

Thank you very much for your reading. Please Click Here. Then Get COMPLETE MANUAL. NO WAITING



NOTE:

If there is no response to click on the link above, please download the PDF document first and then click on it.



